



---

**1990**

---

**BMW 325iX**

---

**Electrical**

---

**Troubleshooting**

---

**Manual**

---

**BMW of North America, Inc.  
Woodcliff Lake, New Jersey**

## **FOREWORD**


In the interests of continuing technical development work we reserve the right to modify designs and equipment.

Printed in USA

©Copyright BMW of North America, Inc.

Not to be reproduced wholly or in part  
without written permission of BMW of  
North America, Inc.

PN 89 89 1 000 335



**1990  
BMW 325iX  
Electrical  
Troubleshooting  
Manual**

---

**CONTENTS**

---

|                                      |        |
|--------------------------------------|--------|
| Index . . . . .                      | 2      |
| How To Use This Manual . . . . .     | 3      |
| Wire Size Conversion Chart . . . . . | 3      |
| Symbols . . . . .                    | 4      |
| Systematic Troubleshooting . . . . . | 6      |
| Connector Views . . . . .            | 8500-0 |
| Power Distribution Box . . . . .     | 0670-0 |
| Fuse Data . . . . .                  | 0670-1 |
| Component Location Chart . . . . .   | 9000-0 |
| Component Location Views . . . . .   | 7000-0 |
| Splice Location Views . . . . .      | 8000-0 |

---

Index – Alphabetical Listing of Electrical Circuits

|   | PAGE    |  | PAGE    |   | PAGE   |
|---|---------|--|---------|---|--------|
| Active Check Control . . . . .          | 6216-0  |  | 0670-15 | – Front Side Marker . . . . .           | 6314-0 |
| A/C Air Delivery Control . . . . .      | 6421-0  |  | 0670-16 | – Front Turn/Park . . . . .             | 6314-0 |
| A/C Blower Controls . . . . .           | 6413-0  | – G201 . . . . .                       | 0670-15 | – Glove Box . . . . .                   | 6100-1 |
| A/C Compressor Controls . . . . .       | 6452-0  | – G300 . . . . .                       | 0670-17 | – Hazard Switch . . . . .               | 6313-0 |
| A/C Temperature Control . . . . .       | 6411-0  | – G302 . . . . .                       | 0670-16 | – Headlights . . . . .                  | 6312-0 |
| Antilock Braking System (ABS) . . . . . | 3450-0  | Heated Seats . . . . .                 | 5200-0  | – Instrument Cluster . . . . .          | 6300-1 |
| Auto-Charging Flashlight . . . . .      | 6100-1  | Horns . . . . .                        | 6100-0  | – Interior . . . . .                    | 6330-0 |
| Auxiliary Fan . . . . .                 | 6454-0  | Ignition Key Warning . . . . .         | 6131-0  | – License . . . . .                     | 6320-0 |
| Auxiliary Fuse . . . . .                | 0670-2  | Indicators                             |         | – Map Reading Light . . . . .           | 6100-1 |
| Brake Warning System . . . . .          | 3435-0  | – Active Check Control Alarm . . . . . | 6210-1  | – Park . . . . .                        | 6314-0 |
| Central Locking, 2 Door . . . . .       | 5126-0  | – Anti-Lock . . . . .                  | 3450-0  | – Rear Side Marker . . . . .            | 6320-0 |
| Central Locking, 4 Door . . . . .       | 5126-2  | – “Brake Lights” Fault . . . . .       | 6216-1  | – Stop . . . . .                        | 6325-0 |
| Charge . . . . .                        | 1230-0  | – “Brake Lining” Wear . . . . .        | 3435-0  | – Tail . . . . .                        | 6314-0 |
| Cigar Lighter . . . . .                 | 6100-1  | – “Brake” Warning . . . . .            | 3435-0  | – Trunk . . . . .                       | 6320-0 |
| Component Location Chart . . . . .      | 9000-0  | – Charge . . . . .                     | 6210-0  | – Turn/Hazard . . . . .                 | 6313-1 |
| Component Location Views . . . . .      | 7000-0  | – Check Engine . . . . .               | 1360-3  | Light Switch Details . . . . .          | 6300-0 |
| Connector Views . . . . .               | 8500-0  | – “Coolant” Level Fault . . . . .      | 6216-2  | Multi-function Clock . . . . .          | 6581-0 |
| Cruise Control . . . . .                | 6571-0  | – “Engine Oil” Fault . . . . .         | 6216-2  | Power Antenna . . . . .                 | 6500-0 |
| Fuel Economy Gauge . . . . .            | 6210-3  | – Fasten Seatbelts . . . . .           | 6216-2  | Power Distribution . . . . .            | 0670-0 |
| Fuel Gauge . . . . .                    | 6210-1  | – Fog Lights . . . . .                 | 6312-0  | Power Distribution Box . . . . .        | 0670-0 |
| Fuse Data Chart . . . . .               | 0670-1  | – High Beam . . . . .                  | 6312-1  | Power Mirrors . . . . .                 | 5116-0 |
| Fuse Details                            |         | – Inspection . . . . .                 | 6210-2  | Power Windows, 2 Door . . . . .         | 5133-2 |
| – Fuse 4 . . . . .                      | 0670-6  | – LH Turn . . . . .                    | 6313-1  | Power Windows, 4 Door . . . . .         | 5133-0 |
| – Fuse 5 . . . . .                      | 0670-6  | – “License Plate” Fault . . . . .      | 6320-0  | Radio . . . . .                         | 6500-0 |
| – Fuse 6 . . . . .                      | 0670-6  | – “Low Beam” Fault . . . . .           | 6216-0  | Rear Defogger . . . . .                 | 6100-2 |
| – Fuse 8 . . . . .                      | 0670-7  | – Low Fuel Warning . . . . .           | 6210-1  | Seatbelt Warning . . . . .              | 6131-0 |
| – Fuse 9 . . . . .                      | 0670-11 | – Oil Pressure Warning . . . . .       | 6210-1  | Service Interval Indicator . . . . .    | 6210-2 |
| – Fuse 10 . . . . .                     | 0670-8  | – Oil Service . . . . .                | 6210-2  | Speedometer . . . . .                   | 6210-0 |
| – Fuse 12 . . . . .                     | 0670-7  | – “Park Brake” . . . . .               | 3435-0  | Splice Location Views Index . . . . .   | 8000-0 |
| – Fuse 19 . . . . .                     | 0670-7  | – “Rear Lights” Fault . . . . .        | 6314-0  | Start, Automatic Transmission . . . . . | 1240-0 |
| – Fuse 20 . . . . .                     | 0670-9  | – RH Turn . . . . .                    | 6313-1  | Start, Manual Transmission . . . . .    | 1240-1 |
| – Fuse 21 . . . . .                     | 0670-10 | – “Washer Fluid” Fault . . . . .       | 6216-2  | Sunroof . . . . .                       | 5413-0 |
| – Fuse 27 . . . . .                     | 0670-11 | Injection Electronics . . . . .        | 1360-0  | Supplemental Restraint System (SRS)     |        |
| Gauges . . . . .                        | 6210-1  | Instrument Cluster . . . . .           | 6210-0  | . . . . .                               | 3234-0 |
| Ground Distribution                     |         | Lights                                 |         | Tachometer . . . . .                    | 6210-3 |
| – G103 . . . . .                        | 0670-12 | – A/C Control Power . . . . .          | 6300-1  | Temperature Gauge . . . . .             | 6210-1 |
| – G104 . . . . .                        | 0670-13 | – Back Up . . . . .                    | 6322-0  | Warnings                                |        |
| – G200 . . . . .                        | 0670-13 | – Fog . . . . .                        | 6312-0  | – Ignition Key/Seatbelt . . . . .       | 6131-0 |
| . . . . .                               | 0670-14 | – Front Ashtray . . . . .              | 6300-1  | Wiper/Washer . . . . .                  | 6160-0 |

The purpose of this manual is to show electrical schematics in a manner that makes electrical troubleshooting easier. Electrical components which work together are shown together on one schematic. The Wiper-Washer schematic, for example, shows all of the electrical components in one diagram. At the top of the page is the fuse (positive) that powers the circuit. The flow of current is shown through all wires, connectors, switches, and motors to ground (negative) at the bottom of the page.

Within the schematic, all switches and sensors are shown "at rest," as though the Ignition Switch were off. For identification, component names are underlined and placed next to or above each component. Notes are included, describing how switches and other components work.

The power distribution schematic shows the current feed through all the connections from the Battery and Alternator to each fuse and the Ignition and Light Switches. If the Power Distribution schematic is combined with any other circuit schematic, a complete picture is made of how that circuit works. The Ground Distribution schematics show how several circuits are connected to common grounds.

All wiring between components is shown exactly as it exists in the vehicle; however, the wiring is not drawn to scale. To aid in understanding electrical operation, wiring inside complicated components has been simplified. The "Solid State" label designates electronic components.


| WIRE SIZE<br>CONVERSION CHART                          |                                 |
|--|---------------------------------|
| METRIC<br>(CROSSSECTIONAL AREA<br>IN MM <sup>2</sup> ) | AWG<br>(AMERICAN<br>WIRE GAUGE) |
| .5   | 20                              |
| .75  | 18                              |
| 1  | 16                              |
| 1.5  | 14                              |
| 2  | 14                              |
| 2.5  | 12                              |
| 4  | 10                              |
| 6  | 8                               |
| 8  | 8                               |
| 16   | 4                               |
| 20   | 4                               |
| 25   | 2                               |
| 32   | 2                               |

| WIRE INSULATION |        |
|-----------------|--------|
| ABBREVIATIONS   | COLOR  |
| BK              | BLACK  |
| BR              | BROWN  |
| RD              | RED    |
| YL              | YELLOW |
| GN              | GREEN  |
| BU              | BLUE   |
| VI              | VIOLET |
| GY              | GRAY   |
| WT              | WHITE  |
| PK              | PINK   |


# 4 SYMBOLS



ENTIRE COMPONENT SHOWN




PART OF A COMPONENT SHOWN




COMPONENT WITH SCREW TERMINALS




SOLID STATE (INCLUDES ONLY ELECTRONIC PARTS)








COMPONENT CASE IS DIRECTLY ATTACHED TO METAL PART OF CAR (GROUNDED)




HOT AT ALL TIMES  
INDICATES THAT FUSE 5 IS ALWAYS SUPPLIED WITH POWER



HOT IN RUN OR START  
INDICATES THAT FUSE 6 IS SUPPLIED WITH POWER WITH THE IGNITION SWITCH IN THE RUN OR START POSITIONS





WIRE CHOICES FOR OPTIONS ARE SHOWN AND LABELED



DIODE CURRENT CAN FLOW ONLY IN THE DIRECTION OF THE ARROW

CIRCUIT REFERENCE - A WIRE WHICH CONNECTS TO ANOTHER CIRCUIT






ONE POLE,  
TWO POSITION  
SWITCH




SWITCHES THAT  
MOVE TOGETHER  
DASHED LINE SHOWS  
A MECHANICAL  
CONNECTION  
BETWEEN SWITCHES




TWO CONNECTIONS  
(PINS) IN THE SAME  
CONNECTOR

DASHED LINE SHOWS  
PARTS OF THE  
SAME CONNECTOR






WHEN COIL IS  
ENERGIZED,  
SWITCH  
IS PULLED CLOSED

RELAY SHOWN  
WITH NO  
CURRENT  
FLOWING  
THROUGH  
COIL



RESISTOR ACROSS COIL  
IS FOR NOISE  
SUPPRESSION

RELAY SHOWN  
WITH RESISTOR  
ACROSS COIL




LOW  
BEAM  
RELAY

2.5 YL

TO POWER  
DISTRIBUTION  
BOX, PAGE 1


CURRENT PATH  
IS CONTINUED  
AS LABELED.  
THE ARROW SHOWS  
DIRECTION OF CURRENT  
FLOW AND IS REPEATED  
WHERE CURRENT  
PATH CONTINUES.



TWO POLE, FOUR  
POSITION SWITCH

IGNITION  
SWITCH

"R" IS ENERGIZED  
IN ACCY, RUN OR START



FROM LOW  
BEAM RELAY,  
PAGE 5

POWER  
DISTRIBUTION  
BOX



LIGHT  
EMITTING  
DIODE

## 6 SYSTEMATIC TROUBLESHOOTING

### TROUBLESHOOTING PROCEDURE

#### 1. Verify the Problem

Operate the problem circuit to check the accuracy of the complaint. Note the symptoms of the inoperative circuit.

#### 2. Analyze the Problem

Refer to the schematic of the problem circuit in the ETM. Determine how the circuit is supposed to work by tracing the current path(s) from the power feed through the circuit components to ground. Then based on the symptoms you noted in step 1 and your understanding of circuit operation, identify one or more possible causes of the problem.

#### 3. Isolate the Problem

Make circuit tests to prove or disprove the preliminary diagnosis made in step 2. Keep in mind that a logical simple procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points which are easily accessible.

#### 4. Repair the Problem

Once the specific problem is identified, make the repair using the proper tools and safe procedures.

#### 5. Check the Problem

Operate the circuit to check for satisfactory circuit operation. Good repair practice calls for rechecking all circuits you have worked on.

### TROUBLESHOOTING TOOLS


Isolating the problem (Step 3 of TROUBLESHOOTING PROCEDURES) requires the use of a **voltmeter** and/or **ohmmeter**. A voltmeter measures voltage at selected points in a circuit. An ohmmeter measures a circuit's resistance to current flow. It has an internal battery that provides current to the circuit under test. Disconnect the car battery when using an ohmmeter because the battery voltage will cause the ohmmeter to give false readings. Also, do not use an ohmmeter on solid-state components. The voltage that the ohmmeter applies to the circuit could damage these components.

### TROUBLESHOOTING TESTS

#### Voltage Test

This test measures voltage in a circuit. By taking measurements at several points (terminals or connectors) along the circuit, you can isolate the problem.

To take a voltage measurement, connect the negative lead of the voltmeter to the battery's negative terminal or other known good ground. Then connect the positive lead of the voltmeter to the point you want to test. The voltmeter will measure the voltage present at that point in the circuit.




Voltage Test



Voltage Drop Test

Wires, connectors, and switches are designed to conduct current with a minimum loss of voltage. A voltage drop of more than one volt indicates a problem.


To test for voltage drop, connect the voltmeter leads to connectors at either end of the circuit's suspected problem area. The positive lead should be connected to the connector closest to the power source. The voltmeter will show the voltage drop between these two points.



Voltage Drop Test

Continuity Test

To perform a continuity test, first disconnect the car battery. Then adjust the ohmmeter to read zero while holding the leads together. Connect the ohmmeter leads to connector or terminals at either end of the circuit's suspected problem area. The ohmmeter will show the resistance across that part of the circuit.




Continuity Test

Short Test Using Voltmeter

Remove the blown fuse and disconnect the load. Connect the voltmeter leads to the fuse terminals. The positive lead should be connected to the terminal closest to the power source.

Starting near the POWER DISTRIBUTION BOX, move the wire harness back and forth and watch the voltmeter reading. If the voltmeter registers a reading, there is a short to ground in the wiring. Somewhere in the area of the harness being moved, the wire insulation is worn away and the circuit is grounding.




Short Test Using Voltmeter

## 8 SYSTEMATIC TROUBLESHOOTING

### Short Test Using Ohmmeter

Disconnect the battery. Adjust the ohmmeter to read zero while holding the leads together. Remove the blown fuse and disconnect the load. Connect one lead of the ohmmeter to the fuse terminal that is closest to the load. Connect the other lead to a known good ground.


Starting near the POWER DISTRIBUTION BOX, move the wire harness back and forth and watch the ohmmeter reading. Low or no resistance indicates a short to ground in the wiring. Infinitely high resistance indicates no short.



Short Test Using Ohmmeter

# 0670-0 POWER DISTRIBUTION

## POWER DISTRIBUTION BOX





**FUSE DATA CHART**

| FUSE NO. | SIZE/<br>COLOR | CIRCUIT NAME   |
|----------|----------------|--|
| 1        | 7.5A           | Headlights (also fuses 2, 13, 14);<br>High Beam Indicator.   |
| 2        | 7.5A           | Headlights (also fuses 1, 13, 14).   |
| 3        | 15A            | Auxiliary Fan (also fuses 18, 19, 20).   |
| 4        | 15A            | Lights: Turn/Hazard (also fuse 24);<br>Active Check Control<br>(also fuses 6, 10, 21, 22, 23);<br>Glove Box Light.   |
| 5        | 30A            | Wiper/Washer.  |
| 6        | 7.5A           | Stop Lights;<br>Cruise Control (Also fuse 10);<br>Active Check Control<br>(also fuses 4, 10, 21, 22, 23);<br>Antilock Braking System;<br>Map Reading Light.  |
| 7        | 15A            | Horn.  |
| 8        | 30A            | Rear Defogger (also fuse 23).  |
| 9        | 15A            | Injection Electronics (also fuses 10, 11, 21).   |
| 10       | 7.5A           | Seatbelt Warning (also fuse 21);<br>Cruise Control (also fuse 6);<br>Service Interval Indicator (also fuse 21);<br>Tachometer/Fuel Economy Gauges<br>(also fuse 21);<br>Gauges/Indicators;<br>Brake Warning System;<br>Back Up Lights;<br>Start;<br>Active Check Control (also fuses 4, 6, 21, 22,<br>23).<br>Injection Electronics (also fuse 9, 11, 21); |
| 11       | 7.5A           | Injection Electronics (also fuses 9, 10, 21).  |
| 12       | 7.5A           | Radio (also fuses 21, 28);<br>Speedometer/Indicators;<br>Multifunction Clock (also fuses 21, 23).  |
| 13       | 7.5A           | Headlights (also fuses 1, 2, 14).  |
| 14       | 7.5A           | Headlights (also fuses 1, 2, 13).  |
| 15       | —              | Not Used.  |
| 16       | 15A            | Heated Seats.  |
| 17       | 30A            | Power Windows, Sunroof.  |
| 18       | 30A            | Auxiliary Fan (also fuses 3, 19, 20).  |
| 19       | 7.5A           | Auxiliary Fan (also fuses 3, 18, 20);<br>Interior Lights (also fuses 21, 27);<br>Power Mirrors.  |


| FUSE NO.                        | SIZE/<br>COLOR | CIRCUIT NAME  |
|---------------------------------|----------------|---|
| 20                              | 30A            | Heater/Air Conditioning;<br>Auxiliary Fan (also fuses 3, 18, 19).   |
| 21                              | 7.5A           | Auto-Charging Flashlight;<br>Ignition Key Warning/Seatbelt Warning;<br>(also fuse 10);<br>Interior Lights (also fuses 19, 27);<br>Radio (also fuses 12, 28);<br>Trunk Light;<br>Active Check Control<br>(also fuses 4, 6, 10, 22, 23);<br>Service Interval Indicator (also fuse 10);<br>Multifunction Clock (also fuses 12, 23);<br>Injection Electronics (also fuses 9, 10, 11);<br>Tachometer/Fuel Economy Gauge<br>(also fuse 10). |
| 22                              | 7.5A           | Active Check Control<br>(also fuses 4, 6, 10, 21, 23);<br>Lights: Front Park/Tail (also fuse 23);<br>Lights: Front Side Marker (also fuse 23).  |
| 23                              | 7.5A           | Lights: Dash<br>Lights: Front Park/Tail (also fuse 22);<br>Lights: Front Side Marker (also fuse 22);<br>Lights: Rear Marker/License;<br>Active Check Control<br>(also fuses 4, 6, 10, 21, 22);<br>Multifunction Clock (also fuses 12, 21);<br>Rear Defogger (also fuse 8).  |
| 24                              | 15A            | Lights: Turn/Hazard (also fuse 4).  |
| 25                              | —              | Not Used.   |
| 26                              | —              | Not Used.   |
| 27                              | 30A            | Interior Lights (also fuses 19, 21);<br>Central Locking;  |
| 28                              | 30A            | Cigar Lighter;<br>Radio/Antenna (also fuses 12, 21).  |
| 29                              | 7.5A           | Fog Lights (also fuse 30); Fog Lights Indicator.  |
| 30                              | 7.5A           | Fog Lights (also fuse 29).  |
| POWER WINDOW<br>CIRCUIT BREAKER |                | 25A Power Windows   |

# 0670-2 POWER DISTRIBUTION






# 0670-4 POWER DISTRIBUTION




POWER DISTRIBUTION BOX







FUSE DETAILS: FUSES 4, 5, AND 6



FUSE DETAILS: FUSES 8, 12 AND 19




FUSE DETAILS: FUSE 10




FUSE DETAILS: FUSE 20



HOT IN RUN ONLY FROM UNLOADER RELAY K7





FUSE DETAILS: FUSE 21




FUSE DETAILS: FUSES 27 AND 9




**GROUND DISTRIBUTION: G103 AND G104**



GROUND DISTRIBUTION: G106 AND G200 (PARTIAL)



★ SPLICE S235 IS FOUND ON SOME VEHICLES. IF S235 DOES NOT EXIST ON A VEHICLE, ALL CIRCUITS GO DIRECTLY TO G200




★ SPLICE S235 IS FOUND ON SOME VEHICLES. IF S235 DOES NOT EXIST ON A VEHICLE, ALL CIRCUITS GO DIRECTLY TO G200.




# 0670-14 POWER DISTRIBUTION

## GROUND DISTRIBUTION: G200 (PARTIAL) AND G201




GROUND DISTRIBUTION: G200 (PARTIAL)




# 0670-16 POWER DISTRIBUTION


## GROUND DISTRIBUTION: G300




# 1230-0 CHARGE




**AUTOMATIC TRANSMISSION**




MANUAL TRANSMISSION



**ENGINE BLOCK DIAGRAM**





ENGINE BLOCK DIAGRAM








ENGINE BLOCK DIAGRAM








# 1360-4 INJECTION ELECTRONICS













# 3234-0 SUPPLEMENTAL RESTRAINT SYSTEM (SRS)






# 3435-0 BRAKE WARNING SYSTEM




# 3450-0 ANTILOCK BRAKING SYSTEM (ABS)





# ANTILOCK BRAKING SYSTEM (ABS) 3450-1

CONTINUED FROM S118  
ON PREVIOUS PAGE




# 3450-2 ANTILOCK BRAKING SYSTEM (ABS)






# 5116-0 POWER MIRRORS




# 5126-0 CENTRAL LOCKING

## 2 DOOR (SELECT)




2 DOOR (CONTROL)






# 5126-2 CENTRAL LOCKING

## 4 DOOR (SELECT)



4 DOOR (CONTROL)



## 5126A-0 CENTRAL LOCKING

### TROUBLESHOOTING HINTS

1. Check Fuse by operating the Interior Light Timer for either Dome Light.
2. If all locks stay in unlock inhibit, check wires to terminal 10 of Central Locking Control Unit for a short to ground.

### SYSTEM CHECK

- Operate controls in sequence listed in the System Check Table.
- Refer to Repair Action for response received (tests follow the System Check Table).
- After any repair, repeat System Check to verify proper system operation.

**NOTE:** Before replacing any system component, check all connectors, splices, and wiring to that component.

**SYSTEM CHECK TABLE**

| OPERATION   | RESPONSE   | REPAIR ACTION                                      |
|---|--|--|
| 1. Insert the key in the Driver's door and turn to LOCK               | All doors lock   | None, proceed to Operation 2                       |
|   | Some doors lock  | Repair/replace the suspect Door Lock Motor circuit |
|   | No doors lock  | Proceed to Operation 4                             |
| 2. Turn the key to UNLOCK INHIBIT (clockwise until key is horizontal) | All doors double lock (Safety Catch Buttons cannot be pulled up by hand) | None, proceed to Operation 3                       |
|   | Driver's door double locks and only some of the other doors double lock  | Repair/replace the suspect Door Lock Motor         |
|   | Driver's door double locks but all the other doors do not double lock    | Perform Test B                                     |
|   | Driver's door does not double lock                                       | Mechanical problem, see BMW Workshop Manual        |

**SYSTEM CHECK TABLE (CONT'D)**

| OPERATION  | RESPONSE                  | REPAIR ACTION  |
|--|---------------------------|--|
| 3. Turn the key to UNLOCK  | All doors unlock          | None, proceed to Operation 4   |
|  | Some doors unlock         | Repair/replace the suspect Door Lock Motor circuit   |
|  | No doors unlock           | Proceed to Operation 5   |
| 4. Insert the key in the Passenger's door and turn to LOCK   | All doors lock            | If the doors did not lock in Operation 1, repair/replace the Driver's Door Lock Switch, otherwise proceed to Operation 5   |
|  | Some doors lock           | Repair/replace the suspect Door Lock Motor circuit   |
|  | No doors lock             | If all the doors locked in Operation 1, repair/replace the Right Front Door Microswitch. If the doors did not lock in Operation 1, perform Test A  |
| 5. Insert the key in the Passenger's door and turn to UNLOCK   | All doors unlock          | If all the doors did not unlock in Operation 3, repair/replace the Driver's Door Lock Switch, otherwise proceed to Operation 6   |
|  | Some doors unlock         | Repair/replace the suspect Door Lock Motor   |
|  | No doors unlock           | If all the doors unlocked in Operation 3, repair/replace the Passenger's Door Lock Switch. If the doors did not unlock in Operation 3, perform Test C  |
| 6. Get in the car and close and lock all doors<br>Turn the Ignition Switch to RUN  | Doors remain locked       | None, proceed to Operation 7   |
|  | Doors unlock              | Repair/replace the Central Locking Control Unit  |
| 7. Get out of the car<br>Insert the key in the Driver's door and turn to LOCK<br>Unlock each of the doors by pulling up the Safety Catch Buttons | All doors can be unlocked | None, proceed to Operation 8   |
|  | All doors remain secure   | Disconnect the connector from the Central Locking Control Unit and check for a short to ground in the wires at terminal 11. <ul style="list-style-type: none"> <li>• If short to ground is not present, replace the Central Locking Control Unit.</li> <li>• If short to ground is present isolate wiring from Door Lock Motors one at a time to find short</li> </ul> |

# 5126A-2 CENTRAL LOCKING

## SYSTEM CHECK TABLE (CONT'D)

| OPERATION  | RESPONSE                   | REPAIR ACTION  |
|--|----------------------------|--|
| 8. Insert the key in the Trunk Cylinder Switch. Turn the key to LOCK | Trunk locks                | None, proceed to Operation 9   |
|  | Trunk does not lock        | If the doors lock, repair/replace the Trunk Lock Motor Circuit or Trunk Lock Motor<br>If the doors do not lock, repair/replace the Trunk Switch<br>Repair/replace the Central Locking Control Unit if the Trunk Switch Circuit is OK     |
| 9. Turn the key to UNLOCK  | Trunk unlocks              | None, proceed to Operation 10  |
|  | Trunk does not unlock      | If the doors unlock, repair/replace the Trunk Lock Motor circuit or Trunk Lock Motor<br>If the doors do not unlock, repair/replace the Trunk Switch<br>Repair/replace the Central Locking Control Unit if the Trunk Switch Circuit is OK |
| 10. Turn the key back to LOCK  | Gas Filler locks           | None, proceed to Operation 11  |
|  | Gas Filler does not lock   | Repair/replace the Gas Filler Lock Motor circuit   |
| 11. Turn the key to UNLOCK   | Gas Filler unlocks         | None   |
|  | Gas Filler does not unlock | Repair/replace the Gas Filler Lock Motor circuit   |

- If all results are normal, system is OK.

### SYSTEM DIAGNOSIS

- Do the following tests when directed by the System Check Table.

#### A: CONTROL UNIT LOCK TEST (TABLE 1)

| Measure: VOLTAGE<br>At: CONTROL UNIT CONNECTOR<br>(Connected)   |                 |               |
|---|-----------------|---------------|
| Measure Between   | Correct Voltage | For Diagnosis |
| 3 & Ground  | Battery         | See 1         |
| 3 & 4   | Battery         | See 2         |
| <ul style="list-style-type: none"> <li>• If voltages are correct, proceed to Table 2.</li> </ul> <ol style="list-style-type: none"> <li>1. Check wire to terminal 3 for an open.</li> <li>2. Check wire from terminal 4 for an open to ground (see schematic).</li> </ol> |                 |               |

#### A: CONTROL UNIT LOCK TEST (TABLE 2)

| Connect: A FUSED JUMPER<br>At: CONTROL UNIT CONNECTOR<br>(Connected)   |                |               |
|--|----------------|---------------|
| Jumper Between   | Correct Result | For Diagnosis |
| 7 & Ground   | Doors lock     | See 1         |
| <ul style="list-style-type: none"> <li>• If the result is correct, repair/replace the switches and related wiring (see schematic).</li> </ul> <ol style="list-style-type: none"> <li>1. Proceed to Table 3.</li> </ol> |                |               |

**A: CONTROL UNIT LOCK TEST  
(TABLE 3)**

| Connect: FUSED JUMPERS<br>At: CONTROL UNIT CONNECTOR<br>(Disconnected)   |                |               |
|--|----------------|---------------|
| Jumper Between   | Correct Result | For Diagnosis |
| 1 & 3<br>2 & 4   | Doors lock     | See 1         |
| <ul style="list-style-type: none"> <li>If the result is correct, replace the Central Locking Control Unit.</li> </ul> <ol style="list-style-type: none"> <li>Check wire from terminal 1 to splice and wire from terminal 3 to splice for opens (see schematic).</li> </ol> |                |               |

**B: UNLOCK INHIBIT TEST**

| Connect: A FUSED JUMPER<br>At: CONTROL UNIT CONNECTOR<br>(Connected)   |                   |               |
|--|-------------------|---------------|
| Jumper Between   | Correct Result    | For Diagnosis |
| 10 & Ground  | Doors double lock | See 1         |
| <ul style="list-style-type: none"> <li>If the result is correct, check wires from terminal 10 to ground for opens (see schematic). Replace the Unlock Inhibit Switch if the wires and connections are OK.</li> </ul> <ol style="list-style-type: none"> <li>Check wires from terminal 11 for opens (see schematic). Replace the Central Locking Control Unit if wires and connections are OK.</li> </ol> |                   |               |

**C: CONTROL UNIT UNLOCK TEST**

| Connect: A FUSED JUMPER<br>At: CONTROL UNIT CONNECTOR<br>(Connected)  |                |               |
|---|----------------|---------------|
| Jumper Between  | Correct Result | For Diagnosis |
| 6 & Ground  | Doors unlock   | See 1         |
| <ul style="list-style-type: none"> <li>If the result is correct, repair/replace the switches and related wiring (see schematic).</li> </ul> <ol style="list-style-type: none"> <li>Replace Central Locking Control Unit.</li> </ol> |                |               |

**CIRCUIT DESCRIPTION**

The Central Locking System is controlled by the Central Locking Control Unit. This unit senses when a lock switch is moved by a key, and sends the appropriate signal to drive the Motors. The Central Locking Control Unit controls the Door Locks, Gas Filler Lock and Trunk Lock. The unit also has an Inertia Switch which closes on impact greater than 5g. If in RUN or START, the locks are then unlocked.

**Lock**

When the Key is inserted into a lock and turned clockwise, the Lock Switch moves to LOCK and grounds terminal 7 of the Central Locking Control Unit. The unit then activates the Lock Relay and applies voltage from Fuse 27 to the Lock Motor, which is grounded through Central Locking Control Unit terminal 2. The Lock Motor then pulls the lock down. The door locks also control the Trunk Lock and Gas Filler Lock.

**Unlock**

When the key is turned counterclockwise, terminal 6 of the Central Locking Control Unit is grounded through the Lock Switch. The Central Locking Control Unit activates the Unlock Relay and applies voltage from Fuse 27, through terminal 2 to the Lock Motor. The motor is grounded through the BU wire, Central Locking Control Unit terminal 1. The polarity is reversed and the motor pushes the lock up.

**Unlock Inhibit**


When the key is inserted into the Driver's Lock and turned clockwise past the LOCK position, the Unlock Inhibit mechanism is engaged. Mechanically inserting a bar into the driver's lock prevents unlocking through use of the Safety Catch Button. When in the Unlock Inhibit position, ground is applied to the Unlock Inhibit motors in the other lock units. The Central Locking Control Unit is grounded at terminal 10 and then activates the Lock Relay. Voltage is applied to the Unlock Inhibit motors through terminal 1. They are activated and engage the other Unlock Inhibit mechanisms. The direction of the motors is reversed when the doors are unlocked (see Unlock).


**Trunk Lock**

The Trunk Lock operates in a manner similar to the Door Locks.

# 5133-0 POWER WINDOWS

## 4 DOOR









# 5133-2 POWER WINDOWS


## 2 DOOR




**HEATED SEATS**



# 5413-0 SUNROOF




# 5413-0 SUNROOF




# 6100-0 BODY ELECTRICAL


## HORNS



**CIGAR LIGHTER/GLOVE BOX LIGHT/AUTO-CHARGING FLASHLIGHT/MAP READING LIGHT**




REAR DEFOGGER



★ SOME VEHICLES MAY CONTAIN AN ADDITIONAL SPLICE. (SEE GROUND DISTRIBUTION)


# 6131-0 IGNITION KEY WARNING/SEATBELT WARNING



★ SOME VEHICLES MAY CONTAIN AN ADDITIONAL SPLICE. (SEE GROUND DISTRIBUTION)




# 6160-0 WIPER/WASHER




# 6210-0 INSTRUMENT CLUSTER

## SPEEDOMETER/INDICATORS




## GAUGES/INDICATOR





# 6210-2 INSTRUMENT CLUSTER

## SERVICE INTERVAL INDICATOR



TACHOMETER/FUEL ECONOMY GAUGE



## ACTIVE CHECK CONTROL

1. When the Ignition Switch is initially placed in "Run," the Active Check Control Arm Indicator flashes, and the Active Check Control Unit Brake Light LED and panel Light LED and panel light illuminate for test purposes. Depressing the brake pedal clears the display.
2. When the Ignition Switch is placed in "RUN," fault monitoring begins. To monitor the low beams, rear lights, or license lights, those circuits must be on. The brake lights are monitored only while the brake pedal is depressed. An exception to this is when all brake light circuits are open. A fault will be indicated with the Ignition Switch in "RUN."
3. When a fault occurs, the alarm indicator flashes, the appropriate LED fault indicator lights, and the panel light goes on for five seconds. Depressing the test button will clear the alarm indicator, but the LED fault indicator remains on.
4. To test the unit, depress the test button. The LED fault indicators and the panel lights should go on.








Figure 1 - Active Check Control Unit Above Rear View Mirror







# 6216-2 ACTIVE CHECK CONTROL








# 6300-0 LIGHT SWITCH DETAILS





DASH LIGHTS




★ SOME VEHICLES MAY CONTAIN AN ADDITIONAL SPLICE. (SEE GROUND DISTRIBUTION)


# 6312-0 HEADLIGHTS/FOG LIGHTS






# 6313-0 TURN/HAZARD LIGHTS







# 6314-0 PARK/TAIL/FRONT MARKER LIGHTS







# 6320-0 REAR MARKER/LICENSE/TRUNK LIGHTS




# 6322-0 BACK UP LIGHTS



# 6325-0 STOP LIGHTS



# 6330-0 INTERIOR LIGHTS



**SYSTEM CHECK**

This procedure provides an overall check of the Heating and Air Conditioning System. Each step can be performed without disassembly or the use of tools.

Complete this procedure with the temperature outside the car above 60 degrees F (16 degrees C) and the engine warm and running at idle.




**SYSTEM CHECK TABLE**

| <b>SET: Temperature Control fully counterclockwise</b><br><b>Upper and Lower Slide Levers to extreme left</b><br><b>Center Slide Lever to extreme right</b><br><b>Blower Speed Control at 0 (OFF)</b> |   |
|---|---|
| ACTION  | NORMAL RESULT   |
| Press Fresh/Recirculating Air Switch (ON).<br>Release A/C button (OFF).   | Fresh/Recirculating pushbutton lights. Blower runs slowly.  |
| Rotate Blower Speed Control through steps 1 to 4  | Blower speed increases at each step to maximum speed at Step 4  |
| Press Fresh/Recirculating Air Switch to release it (OFF)  | Fresh/Recirculating button is no longer lit. Outside air is drawn into car. (The sound of Flap Door Motors may be heard repositioning flaps.) |
| Rotate Temperature Control at least 1/4 turn clockwise  | Air flow becomes warm   |
| Depress A/C button (ON)   | A/C button lights. A/C Compressor runs. Auxiliary Cooling Fan runs.   |
| Press A/C button to release it (OFF)  | A/C button is no longer lit.<br>A/C Compressor turns off.<br>Auxiliary Cooling Fan turns off.   |
| Set Blower Speed Control to 0 (OFF)   | Blower turns off  |

- If all of the steps can be completed as described, the Heating and Air Conditioning System is operating normally.

**HEATING AND AIR CONDITIONING (HOT WATER CONTROL)**

**HOT IN RUN ONLY FROM UNLOADER RELAY K7**



★ SOME VEHICLES MAY CONTAIN AN ADDITIONAL SPLICE. (SEE GROUND DISTRIBUTION)

**CIRCUIT OPERATION**

The Water Shut-Off Solenoid controls the flow of engine coolant through the heater core. When the Solenoid is energized, coolant flow is shut off to allow maximum cooling from the Air Conditioning System. The Water Shut-Off Solenoid is controlled by the Hot Water Cut-Off Switch, which is part of the A/C Control Panel TEMP Control.

Battery voltage is applied through Fuse 20 to the Hot Water Cut-Off Switch with the Ignition Switch in RUN. The Hot Water Cut-Off Switch is closed when the TEMP Control is rotated fully counterclockwise (coldest position), and opens when the control is rotated more than 20 degrees in a clockwise direction. When the switch is closed, battery voltage is applied through the A/C In-Line Fuse to the Water Shut-Off Solenoid. The solenoid is energized and shuts off the coolant flow through the heater core.

Whenever the Water Shut-Off Solenoid is de-energized, the collapsing magnetic field induces high voltage in the coil. The A/C In-Line Diode in the 325 provides a path for the voltage so that it does not damage the contacts of the Hot Water Cut-Off Switch.

The Water Shut-Off Solenoid and A/C In-Line Diode are protected by the A/C In-Line Fuse. If any failures occur in the Solenoid or Diode, the Fuse will isolate them to prevent the failure from affecting other parts of the Heating and Air Conditioning Circuits.

**TROUBLESHOOTING HINTS**

- Try the following checks before doing the System Diagnosis.
- 1. Check that Water Shut-Off Solenoid connector is firmly seated.
- 2. Check A/C In-Line Fuse. If fuse is blown, check for a shorted A/C In-Line Diode.
- Go to Heating and Air Conditioning (6410A-0) System Check for a guide to normal operation.
- Go to System Diagnosis for diagnostic tests.

**SYSTEM DIAGNOSIS**

- Do the following test if the Water Shut-Off Solenoid does not operate normally.

**WATER SHUT-OFF SOLENOID TEST (TABLE 1)**

| Measure: VOLTAGE<br>At: WATER SHUT-OFF SOLENOID CONNECTOR (Disconnected)<br>Conditions:<br>• Ignition Switch: RUN<br>• A/C Control Panel TEMP Control: FULLY COUNTERCLOCKWISE |                 |               |
|---|-----------------|---------------|
| Measure Between   | Correct Voltage | For Diagnosis |
| BU & Ground   | Battery         | See 1         |
| BU & BR/RD or BR  | Battery         | See 2         |
| • Rotate A/C Control Panel TEMP Control to Mid Position   |                 |               |
| BU & Ground   | 0 Volts         | See 3         |

(Continued in next column)

(Continued from previous column)


- If all voltages are correct, replace the Water Shut-Off Solenoid.
- 1. Check the BU wire and A/C In-Line Fuse for an open. If fuse is open, check that A/C In-Line Diode is not shorted. If it is, replace it. If wire, Fuse and Diode are good, go to Table 2.
- 2. Check the BR/RD or BR wire for an open to ground. Check that connector C204 is properly mated.
- 3. Check BU wire for a wire to wire short to voltage. If wire is good, replace the A/C Control Panel TEMP Control.

**WATER SHUT-OFF SOLENOID TEST (TABLE 2)**

| Measure: VOLTAGE<br>At: HOT WATER CUT-OFF SWITCH CONNECTOR (Disconnected)<br>Conditions:<br>• Ignition Switch: RUN<br>• Water Shut-Off Solenoid: CONNECTED |                 |               |
|--|-----------------|---------------|
| Measure Between  | Correct Voltage | For Diagnosis |
| GN/BR & Ground   | Battery         | See 1         |
| GN/BR & BU   | Battery         | See 2         |
| • If both voltages are correct, replace the A/C Control Panel TEMP Control.  |                 |               |
| 1. Check the GN/BR wire for an open back to Fuse 20.   |                 |               |
| 2. Check the BU wire for an open.  |                 |               |

# 6413-0 A/C BLOWER CONTROLS

## HEATING AND AIR CONDITIONING (BLOWER CONTROLS)





**CIRCUIT OPERATION**

With the Ignition Switch in RUN, battery voltage is applied to the Control Switches and Blower Speed Control through the GN/BR wires. If either the A/C Select Switch or the Fresh/Recirculating Air Switch are ON or the Blower Speed Control is in position 1, battery voltage is applied through the YL wire to the Blower Resistors and Blower Motor.

The Blower Motor is a variable speed motor which runs at a speed proportional to the voltage applied to it. With all of the Blower Resistors in the circuit, the voltage applied to the motor is reduced so the motor runs at a low speed.

As the Blower Speed Control is moved through positions 2 and 3, some resistors are bypassed, allowing more voltage to be applied to the Blower Motor, which then runs at a higher speed. When the Blower Speed Control is moved to position 4, battery voltage is applied directly to the Blower Motor, which then runs at maximum speed.

The Blower Resistors dissipate heat because of the current flowing through them. They are cooled by the air flow from the blower. If there is insufficient air flow to cool the resistors, the safety switch will open, shutting the Blower Motor off until the resistors have cooled.

**TROUBLESHOOTING HINTS**

- Try the following checks before doing the System Diagnosis.
- 1. Check Fuse 20 by visual inspection.
- 2. If Blower will run in high only, check the Blower Resistors' Safety Switch for an open.

- Go to Heating and Air Conditioning (6410-0) System Check for a guide to normal operation.
- Go to System Diagnosis for diagnostic tests.

**SYSTEM DIAGNOSIS**

- Do the tests listed for your symptom in the Symptom Table below.
- Tests follow the Symptom Table.

**SYMPTOM TABLE**

| SYMPTOM  | DO TEST |
|--|---------|
| Blower Motor does not run in any speed setting                     | B       |
| Blower runs only in HIGH (does not run in any other speed setting) | B       |
| Blower does not run in some modes                                  | A       |
| Blower does not run with A/C ON or in Recirculating mode           | A       |
| A/C Select Switch or Fresh/Recirculating Air Switch does not light | A       |

**A: CONTROL SWITCH VOLTAGE TEST**

| Measure: VOLTAGE<br>At: CONTROL SWITCHES CONNECTOR (Disconnected)<br>Conditions:<br>• Ignition Switch: RUN<br>• Blower Speed Control: OFF   |                 |               |
|---|-----------------|---------------|
| Measure Between   | Correct Voltage | For Diagnosis |
| 1 (GN/BR) & Ground  | Battery         | See 1         |
| 1 (GN/BR) & 3 (YL)  | Battery         | See 2 & 4     |
| 7 (GN/BR) & Ground  | Battery         | See 1         |
| 7 (GN/BR) & 5 (YL)  | Battery         | See 2 & 4     |
| 7 (GN/BR) & 6(BR/WT)  | Battery         | See 3         |
| • If all voltages are correct, do Test B.<br>1. Check the GN/BR wire for an open.<br>2. Check the YL wire for an open.<br>3. Check the BR/WT wire for an open.<br>4. If voltage is not present between the GN/BR wire and both the YL wires (terminals 3 and 5), do Test B. |                 |               |

**B: BLOWER SPEED CONTROL TEST**

| <b>Measure: VOLTAGE</b><br><b>AT: BLOWER SPEED CONTROL CONNECTOR (Disconnected)</b><br><b>Conditions:</b> <ul style="list-style-type: none"> <li>• Ignition Switch: RUN</li> <li>• A/C Select Switch: ON (Depressed)</li> <li>• Fresh/Recirculating Air Switch: FRESH (Not Depressed)</li> </ul>   |                 |                   |
|--|-----------------|-------------------|
| Measure Between  | Correct Voltage | For Diagnosis     |
| 4 (GN/BR) & Ground   | Battery         | See 1             |
| 7 (YL) & Ground  | Battery         | See 2             |
| • A/C Select Switch: OFF (Not Depressed)   |                 |                   |
| 7 (YL) & Ground  | 0 Volts         | See 3             |
| 4 (GN/BR) & 7 (YL)   | Battery         | See 4, 8, 9, & 10 |
| 4 (GN/BR) & 1 (BK)   | Battery         | See 5, 8, 9, & 10 |
| 4 (GN/BR) & 2 (GN)   | Battery         | See 6, 8, 9, & 10 |
| 4 (GN/BR) & 3 (BU)   | Battery         | See 7 & 10        |
| <ul style="list-style-type: none"> <li>• If all voltages are correct, replace the Blower Motor.</li> </ul> <ol style="list-style-type: none"> <li>1. Check the GN/BR wire for an open.</li> <li>2. Check the YL wire for an open between Blower Speed Control and splice S231.</li> <li>3. Check the YL wire for a wire to wire short to voltage.</li> </ol> |                 |                   |

(Continued in next column)

(Continued from previous column)


|   |
|---|
| <ol style="list-style-type: none"> <li>4. Check the YL wire for an open between splice S231 and the Blower Resistors.</li> <li>5. Check the BK wire for an open.</li> <li>6. Check the GN wire for an open.</li> <li>7. Check the BU wire for an open.</li> <li>8. If voltage is not present at the YL wire, but is present at the GN wire or BK wire, replace the Blower Resistors.</li> <li>9. If voltage is not present at the YL, BK or GN wires, check for an open Blower Resistors' Safety Switch.</li> <li>10. If voltage is not present at the YL, BK, GN and BU wires, do Test C.</li> </ol> |
|---|

**C: BLOWER MOTOR TEST**

| <b>Measure: VOLTAGE</b><br><b>At: BLOWER MOTOR CONNECTOR (Disconnected)</b><br><b>Conditions:</b> <ul style="list-style-type: none"> <li>• Ignition Switch: RUN</li> <li>• A/C Select Switch: ON</li> <li>• Blower Speed Control: HIGH</li> </ul>  |                 |               |
|--|-----------------|---------------|
| Measure Between  | Correct Voltage | For Diagnosis |
| BU & Ground  | Battery         | See 1         |
| BU & BR  | Battery         | See 2         |
| <ul style="list-style-type: none"> <li>• If both voltages are correct, replace the Blower Motor.</li> </ul> <ol style="list-style-type: none"> <li>1. Check the BU wire for an open. If wire is good, recheck Test B.</li> <li>2. Check the BR wire to ground G200 for an open.</li> </ol> |                 |               |

# 6421-0 A/C AIR DELIVERY CONTROL

## HEATING AND AIR CONDITIONING (FRESH/RECIRCULATING AIR CONTROLS)



**CIRCUIT OPERATION**

When the Ignition Switch is in RUN, battery voltage is applied to terminal 7 of the Control Switches, the normally open contacts of the LH Fresh/Recirculating Air Relay, and the normally closed contacts of the RH Fresh/Recirculating Air Relay. If the Fresh/Recirculating Air Switch is not depressed (open), battery voltage is applied through the normally closed contacts of the RH Fresh/Recirculating Air Relay to both Fresh/Recirculating Air Flap Door Motors and then to ground through the normally closed contacts of the LH Fresh/Recirculating Air Relay. Both motors operate and move the Fresh/Recirculating Air Flap Doors to position A, allowing fresh air to enter the blower.

When the Fresh/Recirculating Air Switch is depressed (closed), battery voltage is applied through the switch to both the LH and RH Fresh/Recirculating Air Relay coils. Both relays are energized. Battery voltage is then applied through the closed contacts of the LH Fresh/Recirculating Air Relay to the Flap Door Motors, and to ground through the closed contacts of the RH Fresh/Recirculating Air Relay. Since the voltage is now applied to the Flap Door Motors in the opposite direction, the motors reverse direction and move the Fresh/Recirculating Air Flap Doors to position B, allowing only recirculating air to enter the blower. Both of the Air Flap Door Motors remain energized continuously. When the doors reach the end of their travel, the motors stall and hold the doors in position.

**TROUBLESHOOTING HINTS**

- Try the following checks before doing the System Diagnosis.
- 1. Check that LH and RH Fresh/Recirculating Air Relays are firmly seated.
- 2. Check that LH and RH Fresh/Recirculating Air Relay pigtail connectors are properly mated.
- Go to Heating and Air Conditioning (6410-0) System Check for a guide to normal operation.
- Go to System Diagnosis for diagnostic tests.

**SYSTEM DIAGNOSIS**

- Do the tests below if the Fresh/Recirculating Air Flap Doors do not operate.

**A: FRESH/RECIRCULATING AIR FLAP DOOR MOTOR VOLTAGE TEST**

| Measure: VOLTAGE<br>At: FRESH/RECIRCULATING AIR FLAP DOOR MOTOR PIGTAIL CONNECTORS (Disconnected)<br>Conditions:<br>• Ignition Switch: RUN<br>• Fresh/Recirculating Air Switch: RELEASED (FRESH) |                 |               |
|--|-----------------|---------------|
| Measure Between  | Correct Voltage | For Diagnosis |
| WT and Ground  | Battery         | See 1         |
| WT and YL  | Battery         | See 2         |
| • Fresh/Recirculating Air Switch: DEPRESSED (RECIRCULATING)  |                 |               |
| YL and Ground  | Battery         | See 3         |

(Continued in next column)

(Continued from previous column)

|  |         |       |
|--|---------|-------|
| YL and WT  | Battery | See 3 |
| • If all voltages are correct, replace the inoperative motor.<br>1. Check the WT wire for an open. If wire is good, do Test B for RH Air Relay.<br>2. Check the YL wire for an open. If wire is good, do Test B for LH Air Relay.<br>3. Do Test B for both Air Relays. |         |       |

**B: FRESH/RECIRCULATING AIR RELAY VOLTAGE TEST**

| Measure: VOLTAGE<br>At: FRESH/RECIRCULATING AIR RELAY CONNECTOR (Disconnected)<br>Conditions:<br>• Ignition Switch: RUN<br>• Fresh/Recirculating Air Switch: DEPRESSED (RECIRCULATING)<br>• Fresh/Recirculating Air Flap Door Motor Connectors: CONNECTED |                 |               |
|---|-----------------|---------------|
| Measure Between   | Correct Voltage | For Diagnosis |
| 87 (GN/BR) and Ground   | Battery         | See 1         |
| 86 (GN) and Ground  | Battery         | See 2         |
| 86 (GN) and 85 (BR)   | Battery         | See 3         |
| 86 (GN) and 87a (BR)  | Battery         | See 3         |

(Continued on next page)

(Continued from previous page)



- If all voltages are correct, replace the suspect Fresh/Recirculating Air Relay.
- 1. Check the GN/BR wire for an open.
- 2. Check the GN wire back to the Control Switches for an open. If wire is good, do Test C.
- 3. Check the BR wire for an open.

**C: CONTROL SWITCHES VOLTAGE TEST**


| <b>Measure: VOLTAGE</b><br><b>At: CONTROL SWITCHES CONNECTOR</b><br>(Disconnected)<br><b>Condition:</b><br>• Ignition Switch: RUN  |                 |               |
|--|-----------------|---------------|
| Measure Between  | Correct Voltage | For Diagnosis |
| 7 (GN/BR) & Ground   | Battery         | See 1         |
| 7 (GN/BR) & 8 (GN)   | Battery         | See 2         |
| <ul style="list-style-type: none"> <li>• If both voltages are correct, replace the Control Switches.</li> <li>1. Check the GN/BR wire for an open. If wire is good, check that connector C204 is properly mated.</li> <li>2. Check the GN wire for an open between the Control Switches and the LH and RH Fresh/Recirculating Air Relays.</li> </ul> |                 |               |

# 6452-0 A/C COMPRESSOR CONTROLS

## HEATING AND AIR CONDITIONING (COMPRESSOR CONTROLS)



HEATING AND AIR CONDITIONING (COMPRESSOR CONTROLS)



**CIRCUIT OPERATION**

When the Ignition Switch is in RUN, battery voltage is applied through Fuse 20 to the A/C Select Switch. When the A/C Select Switch is pressed voltage is applied to terminal 3 of the Evaporator Temperature Regulator. The Evaporator Temperature Regulator applies voltage from terminal 2 to the Compressor Clutch through the Refrigerant Pressure Switch.

The Refrigerant Pressure Switch will disengage the Compressor Clutch when refrigerant pressure rises above 435 PSI (30.0 Bar), or when a loss of refrigerant brings the pressure below 21 PSI (1.5 Bar). The Evaporator Temperature Regulator will detect the Refrigerant Pressure Switch opening at terminal 5 and will turn off the output voltage at the Compressor Control terminal. The Evaporator Temperature Regulator will not allow the Compressor Clutch to be turned on again until circuit continuity has been restored between terminals 5 and 2. The Evaporator Temperature Regulator tests for continuity by momentarily applying voltage at the Compressor Control every 8 to 10 seconds. Voltage at the A/C Clutch Monitor Input indicates continuity. The Evaporator Temperature Regulator will continue to apply voltage at the Compressor Control output, which will energize the Compressor Clutch.

**Clutch Diode**

Whenever the Compressor Clutch is de-energized, the collapsing magnetic field induces a voltage in the winding. The Clutch Diode provides a path for the resulting current.

**A/C On Input**

When the Compressor Clutch is turned on, voltage is applied to terminal 29 of the Motronic Control Unit. The Motronic Control Unit uses this signal increase idle speed to compensate for the increased engine load from the Compressor Clutch engaging.

**TROUBLESHOOTING HINTS**

- Try the following checks before doing the System Diagnosis.
  1. Check Fuse 20 by visual inspection.
  2. Check that Compressor Clutch connector is firmly seated.
- Go to Heating and Air Conditioning (6410A-0) System Check for a guide to normal operation.
- Go to System Diagnosis for diagnostic tests.

**SYSTEM DIAGNOSIS**

- Do the tests listed for your symptom in the Symptom Table below.
- Tests follow the Symptom Table.

**SYMPTOM TABLE**

|   |   |
|---|---|
| Compressor Clutch does not engage                                   | A |
| Engine idle speed is not high enough when Compressor Clutch engages | D |

**A: A/C ISOLATION TEST (TABLE 1)**

| Measure: VOLTAGE<br>At: EVAPORATOR TEMPERATURE REGULATOR (Disconnected)<br>Conditions: <ul style="list-style-type: none"> <li>• Ignition Switch: RUN (Engine need not be running)</li> <li>• A/C Selector Switch: ON (Depressed)</li> </ul> |                 |               |
|---|-----------------|---------------|
| Measure Between   | Correct Voltage | For Diagnosis |
| 3 & Ground  | Battery         | See 1         |
| • If voltage is correct, go to Table 2.<br>1. Go to Test E.   |                 |               |



**A: A/C ISOLATION TEST (TABLE 2)**

| Connect: FUSED JUMPER<br>At: EVAPORATOR TEMPERATURE REGULATOR (Disconnected)<br>Conditions:<br>• Ignition Switch: RUN<br>• A/C Selector Switch: ON (Depressed) |                           |               |
|--|---------------------------|---------------|
| Connect Across   | Correct Result            | For Diagnosis |
| 2 & 3  | Compressor Clutch Engages | See 1         |
| • If result is correct go to Test C.<br>1. Go to Test B.   |                           |               |

**B: PRESSURE SWITCH TEST**

| Measure: RESISTANCE<br>At: EVAPORATOR TEMPERATURE REGULATOR CONNECTOR (Disconnected)<br>Conditions:<br>• Ignition Switch: OFF<br>• Negative Battery Terminal: DISCONNECTED  |                           |               |
|---|---------------------------|---------------|
| Measure Between   | Correct Resistance        | For Diagnosis |
| 2 & Ground  | Approximately 3 to 4 ohms | See 1         |
| • If measurement is correct replace the Evaporator Temperature Regulator.<br>1. Check for an open Refrigerant Pressure Switch, A/C Temperature Switch, or associated wiring (see schematic). If Refrigerant Pressure Switch is open, check refrigerant pressure to be sure it is normal before replacing the switch. Replace the A/C Temperature Switch if it is open and engine coolant temperature is below 226°C (108°C). If the switches and related wiring is OK, replace the Compressor Clutch. |                           |               |

**C: EVAPORATOR TEMPERATURE REGULATOR VOLTAGE AND RESISTANCE TEST**

| Measure: RESISTANCE<br>At: EVAPORATOR TEMPERATURE REGULATOR CONNECTOR (Disconnected)<br>Conditions:<br>• Ignition Switch: OFF<br>• Negative Battery Terminal: DISCONNECTED   |  |               |
|--|--|---------------|
| Measure Between  | Correct Resistance                             | For Diagnosis |
| 1 & Ground   | Approximately 3.5K to 4.5K ohms at 70°F (21°C) | See 1         |
| 4 & Ground   | Less than 0.5 ohms                             | See 2         |
| 6 & Ground   | Less than 0.5 ohms                             | See 2         |
| 5 & 2  | Less than 0.5 ohms                             | See 3         |
| • If all resistances are correct but Compressor Clutch does not operate normally, replace the Evaporator Temperature Regulator.<br>1. Check the BK/WT wire for an open or a short to ground (see schematic). Check the BR wire for an open (see schematic). If wires are good, replace the Evaporator Temperature Sensor.<br>2. Check the BR wire for an open (see schematic).<br>3. Check BK/RD for an open between terminal 5 and the Refrigerant Pressure Switch. |  |               |

## 6452-4 A/C COMPRESSOR CONTROLS


### D: IDLE SPEED CONTROL VOLTAGE TEST

| <b>Measure: VOLTAGE</b><br><b>At: MOTRONIC CONTROL UNIT CONNECTOR (Connected – Universal Adapter)</b><br><b>Conditions:</b> <ul style="list-style-type: none"> <li>• Ignition Switch: RUN</li> <li>• A/C Control Panel: A/C ON</li> <li>• Temperature Outside Car: Above 60 degrees F (16 degrees C)</li> </ul> |                 |               |
|---|-----------------|---------------|
| Measure Between   | Correct Voltage | For Diagnosis |
| 40 (BK/GY) & Ground   | Battery         | See 1         |
| 41 (VI/GY) & Ground   | Battery         | See 2         |
| <ul style="list-style-type: none"> <li>• If the voltage is correct, repair/replace the Motronic Control Unit.</li> </ul> <ol style="list-style-type: none"> <li>1. Check for an open in the BL/WT and BK/RD wires.</li> <li>2. Check for an open in the VI/GY and BK/VI wires.</li> </ol>                       |                 |               |

### E: A/C SELECT SWITCH VOLTAGE TEST


| <b>Measure: VOLTAGE</b><br><b>At: CONTROL SWITCHES CONNECTOR (Connected)</b><br><b>Conditions:</b> <ul style="list-style-type: none"> <li>• Ignition Switch: RUN</li> <li>• A/C Control Panel: A/C ON</li> <li>• Temperature Outside Car: Above 60 degrees F (16 degrees C)</li> </ul> |                 |               |
|--|-----------------|---------------|
| Measure Between  | Correct Voltage | For Diagnosis |
| 4 (WT) & Ground  | Battery         | See 1         |
| 2 (BK/VI) & Ground   | Battery         | See 2         |
| <ul style="list-style-type: none"> <li>• If both voltages are correct, check connections at Evaporator Temperature Regulator.</li> </ul> <ol style="list-style-type: none"> <li>1. Check for an open in the WT and GN/BR wires.</li> <li>2. Replace the A/C Select Switch.</li> </ol>  |                 |               |

# 6454-0 AUXILIARY FAN




# 6500-0 RADIO/ANTENNA

## WITH SOUND SYSTEM




WITH SOUND SYSTEM



# 6500-2 RADIO/POWER ANTENNA

## RADIO ONLY



## CIRCUIT OPERATION

With the Ignition Switch in ACCY, RUN or START, Fuse 12 provides voltage to turn on the three components in the system. When the Radio Switch is on, voltage is applied to the Radio and the Power Antenna Raise/Lower Input. This voltage is used to control the individual unit's main power supply.

When the Raise/Lower Input of the Power Antenna receives voltage, power is supplied from Fuse 28 to run the motor and raise the Antenna. when voltage is no longer present at the Raise/Lower Input, the Antenna is lowered.

Fuse 21 constantly supplies voltage to the Memory Power Input of the Radio. This allows the Radio to maintain the present settings while it is turned off.

The actual Radio signal originates at the Antenna. It is supplied to the Radio, processed, and output from the Left Channel and Right Channel Outputs. The signal is then input to the Left Front, Left Rear, Right Front and Right Rear Inputs to the Amplifier.

## TROUBLESHOOTING HINTS

- Try the following checks before doing the System Check.
  1. Check power input to the Radio by observing if Instrument Cluster Indicators light.
  2. Check power input to Antenna by observing the Cigar Lighter.
  3. Check memory power to Radio by checking operation of the Glove Box Light.
  4. Check that the Antenna is properly connected.
  5. Before troubleshooting a suspect Speaker, check all connections to that Speaker.
  6. If display shows "CODE" and Radio will not operate, the individual Anti-Theft Code must be entered. Refer to "Anti-Theft" instruction booklet.
  7. Check Radio Fuse located on back of Radio.
  8. If a speaker is inoperative, switch with a good speaker. If still inoperative, check related wiring. Remove Radio for service if wiring is OK.

## SYSTEM CHECK

- Use the System Check Table as a guide to normal operation.
- Refer to System Diagnosis for a list of symptoms and diagnostic steps.

**SYSTEM CHECK TABLE**

| ACTION                                      | NORMAL RESULT  |
|---|--|
| With Ignition Switch in RUN, turn Radio ON. | Antenna extends.<br>Digital display lights.<br>Sound is emitted from all Speakers. |
| Operate Fader Control.                      | Sound volume varies from front to rear   |

- Refer to System Diagnosis when a result is not normal.

## SYSTEM DIAGNOSIS

- Do the tests listed for your symptom in the Symptom Table below.
- Tests follow the Symptom Table.

**SYMPTOM TABLE**

| SYMPTOM                                     | FOR DIAGNOSIS |
|---|---------------|
| Radio does not work (no display, no sound). | Do Test A     |
| LH Speakers or RH Speakers do not operate.  | Do Test B     |

(Continued on next page)

(Continued from previous page)

|  |   |
|--|---|
| Antenna does not extend or retract.      | Check ground wire for an open. Make sure ground G302 is clean and tight. Check wire to Power Antenna for opens. If OK, replace Power Antenna. |
| An individual Speaker does not operate.  | Do Test C   |
| Excessive noise comes from all Speakers. | Do Test D   |

**A: RADIO POWER TEST**

| <b>Measure: VOLTAGE</b>   |                 |               |
|---|-----------------|---------------|
| <b>At: RADIO CONNECTOR C216 (Disconnected) or CONNECTOR C215 (Disconnected)</b>   |                 |               |
| <b>Condition:</b>   |                 |               |
| • Ignition Switch: RUN  |                 |               |
| Measure Between   | Correct Voltage | For Diagnosis |
| C216 & Ground   | Battery         | See 1         |
| C216/2 & C216/1   | Battery         | See 2         |
| C215/2 & Ground   | Battery         | See 3         |
| <ul style="list-style-type: none"> <li>If all voltages are correct, check wire from connector C215 to Radio for an open. If wire is OK, remove Radio for service.</li> </ul> <ol style="list-style-type: none"> <li>Check power input wire for an open.</li> <li>Check ground wire for an open to ground. Make sure ground G200 is clean and tight.</li> <li>Check memory power supply wire for an open.</li> </ol> |                 |               |

**B: SUSPECT SPEAKER TEST**

| <b>Connect: OHMMETER</b>   |                |               |
|--|----------------|---------------|
| <b>At: SUSPECT SPEAKER (Disconnected)</b>  |                |               |
| <b>Condition:</b>  |                |               |
| • Ohmmeter set on Rx 1 scale or Diode Check Scale  |                |               |
| Action   | Correct Result | For Diagnosis |
| Connect Ohmmeter across Speaker Terminals  | Speaker "pops" | See 1         |
| <ul style="list-style-type: none"> <li>If the result is correct, check wires to the Radio for opens or shorts. If OK, removed Radio for service.</li> </ul> <ol style="list-style-type: none"> <li>Replace the suspect Speaker.</li> </ol> |                |               |

**C: NOISE DIAGNOSIS**

- With Radio on and noise present, unplug the Antenna at the back of the Radio.
- If noise is no longer present, it was being picked up by the Antenna. Perform Antenna Noise Test.
  - If noise persists, it is coming in the Radio wiring. Refer to the following Noise Symptom Table.

**ANTENNA NOISE TEST**

| <b>Measure: RESISTANCE</b>   |                                      |               |
|--|--------------------------------------|---------------|
| <b>At: ANTENNA</b>   |                                      |               |
| Measure Between  | Correct Resistance                   | For Diagnosis |
| Antenna Plug Base & Ground   | Less than 3 Ohms                     | See 1         |
| Antenna Plug Tip & Antenna Plug Base   | Greater than 1 Megohm (open circuit) | See 2         |
| <ul style="list-style-type: none"> <li>If both resistances are correct, check the hood ground strap. If OK, substitute different Antenna at Radio. If good, replace Antenna. If noise is still present, refer to Noise Symptom Table.</li> </ul> <ol style="list-style-type: none"> <li>Check ground contact at Antenna base. If necessary, install a braided ground strap from the Antenna Base to Chassis ground. Check for an open in the Antenna Cable.</li> <li>Check for a short to ground at the Antenna or Antenna cable.</li> </ol> |                                      |               |



## D: SUSPECT SPEAKER TEST

| <b>Connect: OHMMETER</b><br><b>At: SUSPECT SPEAKER (Disconnected)</b><br><b>Condition:</b> <ul style="list-style-type: none"> <li>• Ohmmeter set on Rx 1 scale or Diode Check Scale</li> </ul>   |                |               |
|--|----------------|---------------|
| Action   | Correct Result | For Diagnosis |
| Connect Ohmmeter across Speaker Terminals  | Speaker "pops" | See 1         |
| <ul style="list-style-type: none"> <li>• If the result is correct, check wires to the Amplifier or Radio for opens or shorts. If OK, check wires between Amplifier (if equipped) and the Radio. Remove Radio for service.</li> </ul> <ol style="list-style-type: none"> <li>1. Replace the suspect Speaker.</li> </ol> |                |               |

## E: NOISE DIAGNOSIS

With Radio on and noise present, unplug the Antenna at the back of the Radio.

- If noise is no longer present, it was being picked up by the Antenna. Perform Antenna Noise Test.
- If noise persists, it is coming in the Radio wiring. Refer to the following Noise Symptom Table.


## ANTENNA NOISE TEST

| <b>Measure: RESISTANCE</b><br><b>At: ANTENNA</b>   |                                      |               |
|--|--------------------------------------|---------------|
| Measure Between  | Correct Resistance                   | For Diagnosis |
| Antenna Plug Base & Ground   | Less than 3 Ohms                     | See 1         |
| Antenna Plug Tip & Antenna Plug Base   | Greater than 1 Megohm (open circuit) | See 2         |
| <ul style="list-style-type: none"> <li>• If both resistances are correct, check the hood ground strap. If OK, substitute different Antenna at Radio. If good, replace Antenna. If noise is still present, refer to Noise Symptom Table.</li> </ul> <ol style="list-style-type: none"> <li>1. Check ground contact at Antenna base. If necessary, install a braided ground strap from the Antenna Base to Chassis ground. Check for an open in the Antenna Cable.</li> <li>2. Check for a short to ground at the Antenna or Antenna cable.</li> </ol> |                                      |               |


NOISE SYMPTOM TABLE


| SYMPTOM  | POSSIBLE CAUSE   | REPAIR ACTION  |
|--|------------------|--|
| Harsh popping or crackling noise present when ignition on-changes with engine rpm. | Ignition Noise   | <ul style="list-style-type: none"> <li>• Check for proper distributor cap shielding.</li> <li>• Check shielding ground strap. If not present, install.</li> <li>• Check for defective spark plug or spark plug wire.</li> <li>• Reroute spark plug wires laying against anything that could be transmitting noise to the Radio (wiring or sensor leads traveling into the passenger compartment).</li> <li>• Check engine/firewall ground strap and engine hood/body ground strap.</li> <li>• Check if engine hood is closing properly.</li> <li>• Connect dedicated ground strap to Radio.</li> <li>• Replace distributor cap and rotor.</li> </ul> |
| High whine or howling that changes with engine rpm.                                | Alternator noise | <ul style="list-style-type: none"> <li>• Connect dedicated ground strap to Radio.</li> <li>• Run a direct wire from Battery to Alternator.</li> </ul>  |
| AM only is weak and noisy.   | AM alignment     | <ul style="list-style-type: none"> <li>• Remove Radio for service.</li> </ul>  |
| FM only is weak and noisy.   | FM alignment     | <ul style="list-style-type: none"> <li>• Remove Radio for service.</li> </ul>  |

# 6571-0 CRUISE CONTROL



# 6581-0 MULTIFUNCTION CLOCK





NOTE: SEE PAGE 6131-0 FOR REMAINING CHIME MODULE WIRING.




Figure 1 - LH Rear of Engine Compartment




Figure 3 - LH Rear of Engine Compartment (Inside Power Distribution Box)




Figure 5 - Forward of LH Front Shock Tower (Relay Cover Removed)




Figure 2 - LH Rear of Engine Compartment




Figure 4 - Rear of Engine Compartment, Behind Cowl Panel




Figure 6 - LH Front of Engine Compartment




Figure 1 - LH Side of Engine Compartment




Figure 3 - Forward of LH Front Wheel Well




Figure 5 - Lower LH Front of Engine (From Below)




Figure 2 - LH Front of Engine




Figure 4 - Lower LH Rear of Engine




Figure 6 - LH Front of Engine




Figure 1 - Under Middle of Front Bumper




Figure 3 - Top RH Side of Radiator




Figure 5 - RH Front of Engine




Figure 2 - Under RH Side of Front Bumper (LH Similar)




Figure 4 - Top RH Front of Engine




Figure 6 - RH Front of Engine Compartment






Figure 1 - Top RH Front of Engine




Figure 3 - Lower RH Side of Engine




Figure 5 - RH Rear of Engine Compartment




Figure 2 - Lower RH Front of Engine




Figure 4 - RH Rear of Engine Compartment




Figure 6 - RH Rear of Engine Compartment




Figure 1 - Below Center of Car, RH Side of Transmission




Figure 3 - Behind LH Front Wheel (All Others Similar)




Figure 5 - Above LH Front Door Jamb Switch




Figure 2 - Inside Air Intake, Near LH Fog Light




Figure 4 - LH Front Brake Caliper Assembly (RH Rear Similar)




Figure 6 - Above RH Front Door Jamb Switch




Figure 1 - LH Kick Panel




Figure 3 - Under LH Side of Dash




Figure 5 - Under LH Side of Dash, Left of Steering Column




Figure 2 - Behind Left Front Speaker




Figure 4 - Under LH Side of Dash (SRS Knee Pad Dropped)




Figure 6 - Under LH Side of Dash, Left of Steering Column




Figure 1 - Under LH Side of Dash, Left of Steering Column




Figure 3 - Under LH Side of Dash, Left of Steering Column




Figure 5 - Under LH Side of Dash, Left of Steering Column




Figure 2 - Under LH Side of Dash, Left of Steering Column




Figure 4 - Under LH Side of Dash, Below Steering Column




Figure 6 - Under LH Side of Dash, Below Steering Column




Figure 1 - Underside of Steering Column




Figure 3 - Top of Steering Column (Steering Wheel Removed)




Figure 5 - Under LH Side of Dash, Right of Steering Column




Figure 2 - Top of Steering Column (Air Bag Gas Generator Removed)



Figure 4 - Inside Steering Wheel (Removed From Car)




Figure 6 - Center of Dash




Figure 1 - LH Side of Evaporator Housing




Figure 3 - Center of Windshield Header




Figure 5 - Center of Dash




Figure 2 - LH Side of Evaporator Housing




Figure 4 - Center of Windshield Header




Figure 6 - Center of Dash




Figure 1 - Center Console (Manual Transmission)




Figure 3 - Below RH Side of Center Console (Automatic Transmission)




Figure 5 - Inside Glove Box




Figure 2 - Center Console (Automatic Transmission)




Figure 4 - Rear of Center Console




Figure 6 - Under RH Side of Dash, Above Glove Box

# 7000-10 COMPONENT LOCATION VIEWS



Figure 1 - Front of LH Front Door (RH Similar)




Figure 3 - Rear of LH Front Door (RH Similar)




Figure 5 - Front of LH Rear Door (RH Similar)




Figure 2 - Rear of LH Front Door (RH Similar)




Figure 4 - In LH "B" Pillar (RH Similar)




Figure 6 - Rear of LH Rear Door (RH Similar)





Figure 1 - Base of LH "B" Pillar (RH Similar)




Figure 3 - Under LH Side of Rear Seat




Figure 5 - LH Side of Trunk




Figure 2 - Under LH Side of Rear Seat




Figure 4 - Under RH Side of Rear Seat




Figure 6 - LH Side of Trunk

7000-12 COMPONENT LOCATION VIEWS




Figure 1 - RH Front of Trunk




Figure 3 - Center Rear of Trunk




Figure 5 - RH Rear of Rear Differential




Figure 2 - RH Side of Trunk




Figure 4 - Center Rear of Trunk Lid

## 8000-0 SPLICE LOCATION VIEWS

### INDEX

This index lists all the splices in the vehicle, the harness location of each splice, and the page on which each splice appears. The drawings after the index show how the harnesses are routed through the vehicle and the location of the splices on the harnesses.



| <b>SPLICE</b> | <b>HARNESS</b> | <b>PAGE<br/>NUMBER</b> | <b>SPLICE</b> | <b>HARNESS</b> | <b>PAGE<br/>NUMBER</b> |
|---------------|----------------|------------------------|---------------|----------------|------------------------|
| S100          | MAIN           | 8000-2                 | S219          | INSTRUMENT     |                        |
| S101          | ENGINE         | 8000-2                 |               | PANEL          | 8000-5                 |
| S103          | MAIN           | 8000-2                 | S221          | INSTRUMENT     |                        |
| S104          | ENGINE         | 8000-3                 |               | PANEL          | 8000-5                 |
| S105          | ENGINE         | 8000-3                 | S223          | CRUISE         | NOT<br>SHOWN           |
| S106          | ENGINE         | 8000-3                 |               | CONTROL        |                        |
| S107          | ENGINE         | 8000-3                 | S224          | MULTI-         |                        |
| S109          | ENGINE         | 8000-3                 |               | FUNCTION       | NOT<br>SHOWN           |
| S111          | ENGINE         | 8000-3                 |               | CLOCK          |                        |
| S112          | ENGINE         | 8000-3                 | S225          | MULTI-         |                        |
| S113          | ENGINE         | 8000-3                 |               | FUNCTION       | NOT<br>SHOWN           |
| S114          | MAIN           | 8000-2                 |               | CLOCK          |                        |
| S115          | MAIN           | 8000-2                 | S226          | A/C            | NOT<br>SHOWN           |
| S116          | MAIN           | 8000-2                 |               |                |                        |
| S118          | MAIN           | 8000-2                 | S228          | CRUISE         | NOT<br>SHOWN           |
| S119          | MAIN           | 8000-2                 |               | CONTROL        |                        |
| S120          | ENGINE         | 8000-3                 | S229          | AIR            | NOT<br>SHOWN           |
| S207          | MAIN           | 8000-2                 |               | CONDITIONING   |                        |
| S209          | MAIN           | 8000-2                 | S230          | MAIN           | 8000-2                 |
| S210          | MAIN           | 8000-2                 | S231          | MAIN           | 8000-2                 |
| S211          | MAIN           | 8000-2                 | S232          | MAIN           | 8000-2                 |
| S212          | MAIN           | 8000-2                 | S233          | MAIN           | 8000-2                 |
| S213          | MAIN           | 8000-2                 | S234          | MAIN           | 8000-2                 |
| S215          | MAIN           | 8000-2                 | S235          | MAIN           | 8000-2                 |
|               |                |                        | S236          | MAIN           | 8000-2                 |
|               |                |                        | S237          | MAIN           | 8000-2                 |
|               |                |                        | S238          | MAIN           | NOT<br>SHOWN           |

**INDEX**


| <b>SPLICE</b> | <b>HARNESS</b> | <b>PAGE<br/>NUMBER</b> | <b>SPLICE</b> | <b>HARNESS</b> | <b>PAGE<br/>NUMBER</b> |
|---------------|----------------|------------------------|---------------|----------------|------------------------|
| S239          | MAIN           | 8000-2                 | S340          | MAIN           | 8000-2                 |
| S240          | AIR            | NOT                    | S341          | MAIN           | 8000-2                 |
|               | CONDITIONING   | SHOWN                  | S342          | DOOR           | 8000-4                 |
| S241          | MAIN           | 8000-2                 | S345          | RADIO          | NOT                    |
| S250          | AIR            | NOT                    |               |                | SHOWN                  |
|               | CONDITIONING   | SHOWN                  | S400          | RADIO          | NOT                    |
| S251          | AIR            | NOT                    |               |                | SHOWN                  |
|               | CONDITIONING   | SHOWN                  | S402          | DOOR           | 8000-4                 |
| S252          | AIR            | NOT                    | S403          | RADIO          | NOT                    |
|               | CONDITIONING   | SHOWN                  |               |                | SHOWN                  |
| S260          | MAIN           | 8000-2                 | S404          | RADIO          | NOT                    |
| S300          | DOOR           | 8000-4                 |               |                | SHOWN                  |
| S301          | DOOR           | 8000-4                 | S411          | DOOR           | 8000-4                 |
| S302          | DOOR           | 8000-4                 | S420          | RADIO          | NOT                    |
| S303          | DOOR           | 8000-4                 |               |                | SHOWN                  |
| S304          | DOOR           | 8000-4                 | S501          | DOOR           | 8000-4                 |
| S305          | DOOR           | 8000-4                 | S502          | DOOR           | 8000-4                 |
| S306          | INSTRUMENT     |                        | S503          | DOOR           | 8000-4                 |
|               | PANEL          | 8000-5                 | S504          | DOOR           | 8000-4                 |
| S307          | INSTRUMENT     |                        | S540          | HEATED SEATS   | NOT                    |
|               | PANEL          | 8000-5                 |               |                | SHOWN                  |
| S309          | DOOR           | 8000-4                 | S541          | HEATED SEATS   | NOT                    |
| S310          | MAIN           | 8000-2                 |               |                | SHOWN                  |
| S313          | RADIO          | NOT                    | S542          | HEATED SEATS   | NOT                    |
|               |                | SHOWN                  |               |                | SHOWN                  |
| S316          | MAIN           | 8000-2                 | S543          | HEATED SEATS   | NOT                    |
| S319          | MAIN           | 8000-2                 |               |                | SHOWN                  |
| S322          | DOOR           | 8000-4                 | S700          | ENGINE         | 8000-3                 |
| S323          | DOOR           | 8000-4                 | S701          | ENGINE         | 8000-3                 |
| S324          | MAIN           | 8000-2                 | S702          | ENGINE         | 8000-3                 |
| S326          | MAIN           | 8000-2                 | S704          | ENGINE         | 8000-3                 |
| S329          | MAIN           | 8000-2                 |               |                |                        |
| S330          | MAIN           | 8000-2                 |               |                |                        |
| S332          | DOOR           | 8000-4                 |               |                |                        |
| S333          | DOOR           | 8000-4                 |               |                |                        |

# 8000-2 SPLICE LOCATION VIEWS

## MAIN HARNESS SPLICE LOCATIONS




ENGINE HARNESS SPLICE LOCATIONS




# 8000-4 SPlice LOCATION VIEWS

## DOOR HARNESS SPlice LOCATIONS




INSTRUMENT PANEL HARNESS SPLICE LOCATION





# 8500-0 CONNECTOR VIEWS


## DIAGNOSTIC CONNECTOR



DIAGNOSTIC CONNECTOR FACE

| Pin | Wire Size | Wire Color | Circuit and Component Connected                                |
|-----|-----------|------------|--|
| 1   | 1         | BK         | Ignition Coil, Motronic Control Unit                           |
| 6   | .5        | WT/BK      | SRS Connector  |
| 7   | .5        | WT/BU      | Service Interval Indicator, Service Interval Processor (Reset) |
| 11  | 2.5       | BK/YL      | Starter, Start Signal (50)                                     |
| 12  | .75       | BU         | Charge, Alternator (D+)  |
| 14  | 2.5       | RD         | Battery (+)  |
| 15  | .5        | BK/YL      | Motronic Control Unit (RXD)                                    |
| 16  | 1.5       | GN/WT      | Oxygen Sensor/Power (318is)                                    |
| 18  | .5        | GN/BU      | Motronic Control Unit (Programming Voltage)                    |
| 19  | 1.5       | BR         | Ground Distribution (G103)                                     |
| 20  | .5        | WT/VI      | Motronic Control Unit (TXD)                                    |

**CIRCUITS USING C302 (ACCESSORY CONNECTOR)**




**Figure 1-C302 (Accessory Connector)**  
Front View—Under LH Side  
of Dash Ahead of Pedal Assembly

| TERMINAL | CIRCUIT             | TERMINAL | CIRCUIT           |
|----------|---------------------|----------|-------------------|
| A        | Not Used            | N        | Not Used          |
| B        | Not Used            | O        | Not Used          |
| C        | Anti-Lock Braking   | P        | Not Used          |
| D        | Not Used            | Q        | Power Windows     |
| E        | Not Used            | R        | Anti-Lock Braking |
| F        | Not Used            | S        | Cruise Control    |
| G        | Anti-Lock Braking   | T        | Not Used          |
| H        | Multifunction Clock | U        | Not Used          |
| I        | Not Used            | V        | Radio             |
| J        | Not Used            | W        | Radio             |
| K        | Not Used            | X        | Radio             |
| L        | Not Used            | Y        | Radio             |
| M        | Not Used            | Z        | Power Antenna     |


# 8500-2 CONNECTOR VIEWS

B350002.04




Mating Face  
ABS CONTROL UNIT

B070008.00




Mating Face  
AIR FLOW METER  
318is

B120014




Wiring Face  
ABS HYDRAULIC UNIT

B090001.14




Mating Face  
ABS NEUTRAL  
INPUT RELAY




Wiring Face  
AMPLIFIER  
(SOUND SYSTEM)

B050010.00




Mating Face  
AIR FLOW METER  
325i/is, M3, 325ix, 325ic

B080012




Wiring Face  
AUXILIARY FUSE

B260002.01




Mating Face  
ACTIVE CHECK CONTROL

B090005




Mating Face  
A/C COMPRESSOR CONTROL UNIT  
318is

B260002.03




Wiring Face  
CRUISE CONTROL  
UNIT

B080014.00




Wiring Face  
BLOWER SPEED CONTROL

B030015.03




Wiring Face  
BAROMETRIC PRESSURE  
SENSOR




Wiring Face  
CHIME MODULE (C1)


B040013



Wiring Face  
CHIME MODULE (C2)




Wiring Face  
BLOWER RESISTORS



Wiring Face  
CENTRAL LOCKING CONTROL UNIT


# 8500-4 CONNECTOR VIEWS

B080013.00




Wiring Face  
CONTROL SWITCHES

B030019.00




Wiring Face  
DUAL TEMPERATURE SWITCH

B060024




Wiring Face  
EVAPORATOR TEMPERATURE REGULATOR

B030015.05




Mating Face  
CYLINDER IDENTIFICATION SENSOR

B030015.04




Wiring Face  
ENGINE SPEED SENSOR

49A




Wiring Face  
FLASHER


B090001.04



Mating Face  
EVAPORATIVE PURGE VALVE RELAY




Wiring Face  
DOOR LOCK MOTOR



Wiring Face  
FOG LIGHT SWITCH


B090001.17



Mating Face

FRESH/RECIRCULATING AIR RELAY


B030017.00



Wiring Face

FRONT TURN/PARK LIGHT

325i/325is, 325ix




Wiring Face

FRONT TURN/PARK LIGHT

325ic, M3

B030025.00




Mating Face

FRONT TURN/PARK LIGHT

318is

B030015.09




Mating Face

HEADLIGHTS

Low and High Beams

B030015.08




Mating Face

IGNITION COILS

318is


B030020.00



Wiring Face

INSTRUMENT CLUSTER (C6)


B090001.16



Mating Face

INTERIOR LIGHT TIMER CONTROL

B120006.00




Wiring face

LIGHT SWITCH

# 8500-6 CONNECTOR VIEWS


B090001.06



Mating Face

MAIN RELAY


2 6



Mating Face

MIRROR CONTROL SWITCH


B030015.06



Wiring Face

OIL LEVEL SENSOR

B550001.02




Mating Face

MOTRONIC CONTROL UNIT

All except M3 and 318is


B350002



Mating Face

MOTRONIC CONTROL UNIT

B880002.00




Mating Face

MOTRONIC CONTROL UNIT

318is


B260002.00



Wiring Face


ON - BOARD COMPUTER MODULE

B090001.05



Mating Face


OXYGEN SENSOR HEATER RELAY



Wiring Face

REAR DEFOGGER SWITCH


B040012.02



Wiring Face

ON - BOARD COMPUTER RELAY BOX (C2)


B040012.01



Wiring Face

POWER MIRRORS


B060027.00



Wiring Face


REAR LIGHT ASSEMBLY

B040018



Mating Face


OXYGEN SENSOR HEATER 318is



Wiring Face

POWER WINDOW SWITCHES

B060033.00




Wiring Face

REAR LIGHT ASSEMBLY




B080015.01



Wiring Face

REAR LIGHTS CHECK RELAY (C1)


B060028 .01



Wiring Face

REAR LIGHTS CHECK RELAY (C2)


B0400002.03



Mating Face

REAR WINDOW  
BLOWER


B090001.14



Mating Face

REAR WINDOW BLOWER RELAY


B090001.05



Mating Face

SEATBELT WARNING TIMER


B070009.00



Mating Face


SEATBELT AND SRS WARNING MODULE  
318is

B090001.00




Wiring Face

START RELAY



Wiring Face


SUNROOF MOTOR (CI)



Wiring Face


SUNROOF SWITCH

B030015.07




Wiring Face

THROTTLE SWITCH, POTENTIOMETER



Wiring Face


TRUNK LID LOCK MOTOR



Wiring Face

WIPER MOTOR


B200002.00



Wiring Face

C101


B300001.00



Wiring Face

C103

B030004.02



Mating Face

C110


C113



Wiring Face

C114

B040002.00



Wiring Face


C107

C131

C136

C270

B040006.01




Wiring Face


C140

# 8500-10 CONNECTOR VIEWS

B030015.06




Wiring Face  
C152, C153, C154




Wiring Face  
C201

B120004.00




Wiring Face  
C204


B070002.00




Wiring Face  
C191



Wiring Face  
C202




Wiring Face  
C209




Wiring Face  
C200

B060032.00



Wiring Face  
C203

B070004.00



Wiring Face  
C210


B060025



Wiring Face

C240


B060003.03



Mating Face

C242


B080002.00



Mating Face

C243


B030001.01



Wiring Face


C303

C304



Wiring Face

C306




Wiring Face

C404

C405


B050011.00



Wiring Face


C413

B040004.00



C421

C422



Wiring Face

C503

## 9000-0 COMPONENT LOCATION CHART

| COMPONENTS  | Page-Figure  |
|---|--|
| ABS Clutch Switch . . . . .                             | Behind LH side of dash, above clutch pedal . . . . . 7000- 6-6                     |
| ABS Electronic Control<br>Unit . . . . .                | Behind LH side of dash, above hood release . . . . . 7000- 5-5                     |
| ABS Hydraulic Unit . . . . .                            | LH front corner of engine compartment . . . . . 7000- 0-6                          |
| ABS Neutral Input Relay . . . . .                       | Behind LH side of dash, on C302 accessory<br>connector bracket . . . . . 7000- 6-1 |
| Active Check Control Unit . . . . .                     | Above rear view mirror . . . . . 7000- 8-3   |
| Air Bag Gas Generator . . . . .                         | Center of steering wheel . . . . . 7000- 7-4                                       |
| Air Flow Meter . . . . .                                | LH front of engine compartment, behind air<br>cleaner . . . . . 7000- 0-5          |
| Alternator . . . . .                                    | Lower LH front of engine . . . . . 7000- 1-5                                       |
| Amplifier . . . . .                                     | LH side of trunk, above wheel well . . . . . 7000- 11-5                            |
| Auto-Charging Flashlight . . . . .                      | Inside LH side of glove box . . . . . 7000- 9-5                                    |
| Automatic Transmission<br>Range Switch . . . . .        | At base of gear shift lever . . . . . 7000- 9-2                                    |
| Auxiliary Fan . . . . .                                 | In front of radiator . . . . . 7000- 2-1   |
| Auxiliary Fan Normal Speed<br>Blower Resistor . . . . . | In front of radiator, RH side of auxiliary<br>fan . . . . . 7000- 2-1              |
| Auxiliary Fuse . . . . .                                | LH rear of engine compartment, on power<br>distribution box . . . . . 7000- 0-1    |
| Back Up Light Switch . . . . .                          | Top RH side of transmission . . . . . 7000- 4-1                                    |
| Battery . . . . .                                       | In RH rear corner of trunk . . . . . 7000- 12-2                                    |
| Battery Junction Block . . . . .                        | RH rear of engine compartment, on RH<br>bulkhead . . . . . 7000- 3-4               |
| Blower Motor . . . . .                                  | Inside LH side of fresh air intake cowl . . . . . 7000- 0-4                        |
| Blower Resistors . . . . .                              | Inside fresh air intake cowl, inside<br>blower motor housing                       |
| Brake Fluid Level Switch . . . . .                      | LH side of engine compartment, on brake<br>fluid reservoir . . . . . 7000- 0-2     |
| Brake Switch . . . . .                                  | Behind LH side of dash, on brake pedal<br>support . . . . . 7000- 6-4              |
| Brake Wear Sensors . . . . .                            | On LH front and RH rear brake calipers . . . . . 7000- 4-4                         |
| Central Locking Control<br>Unit . . . . .               | Inside LH kick panel, behind LH front<br>speaker . . . . . 7000- 5-2               |
| Chime Module . . . . .                                  | Mounted on LH dash hush panel . . . . . 7000- 5-3                                  |
| Clutch Switch . . . . .                                 | Behind LH side of dash, on clutch pedal<br>support . . . . . 7000- 6-6             |

| COMPONENTS                           | Page-Figure  |
|--------------------------------------|--|
| Combination Switch . . . . .         | Upper LH side of steering column . . . . . 7000- 7-3                               |
| Compressor Clutch . . . . .          | Lower RH front of engine, on A/C<br>compressor . . . . . 7000- 2-5                 |
| Compressor Clutch Diode . . . . .    | Lower RH front of engine, on A/C<br>compressor . . . . . 7000- 2-5                 |
| Coolant Level Switch . . . . .       | In front of LH front wheel well, in<br>coolant reservoir . . . . . 7000- 1-3       |
| Coolant Temperature Sender . . . . . | Top front of engine, top of thermostat<br>housing . . . . . 7000- 3-1              |
| Coolant Temperature Sensor . . . . . | Top front of engine, top of thermostat<br>housing . . . . . 7000- 3-1              |
| Cruise Control Actuator . . . . .    | LH front of engine compartment . . . . . 7000- 1-3                                 |
| Cruise Control Unit . . . . .        | Behind RH side of dash, above glove box . . . . . 7000- 9-6                        |
| Cylinder Identification              |  |
| Sensor . . . . .                     | Top RH front of engine, near distributor . . . . . 7000- 2-4                       |
| Deceleration Sensor . . . . .        | Behind LH front shock tower . . . . . 7000- 0-1                                    |
| Diagnostic Connector . . . . .       | Top LH front of engine . . . . . 7000- 1-2   |
| Driver's Exterior Door               |  |
| Handle Switch . . . . .              | In top rear of LH front door . . . . . 7000- 10-2                                  |
| Dual Temperature Switch . . . . .    | Top RH side of radiator . . . . . 7000- 2-3  |
| Engine Speed Sensor . . . . .        | Lower RH front of engine . . . . . 7000- 2-5                                       |
| Evaporative Purge Valve . . . . .    | Below LH side of throttle body . . . . . 7000- 1-6                                 |
| Evaporator Temperature               |  |
| Regulator . . . . .                  | On LH side of evaporator housing . . . . . 7000- 8-2                               |
| Evaporator Temperature               |  |
| Sensor . . . . .                     | On LH side of evaporator housing . . . . . 7000- 8-2                               |
| Filter Capacitor . . . . .           | Lower LH front of engine, on alternator . . . . . 7000- 1-5                        |
| Flasher . . . . .                    | Upper part of steering column . . . . . 7000- 7-3                                  |
| Fresh/Recirculating Air              |  |
| Flap Door Motors . . . . .           | Behind A/C face plate, on either side of<br>evaporator housing . . . . . 7000- 7-5 |
| Fresh/Recirculating Air              |  |
| Relays . . . . .                     | Behind A/C face plate . . . . . 7000- 7-6  |
| Front Door Lock Motors . . . . .     | Rear part of respective front doors . . . . . 7000- 10-2                           |
| Front Window Motors . . . . .        | Forward part of respective front doors . . . . . 7000- 10-1                        |
| Fuel Injectors . . . . .             | Below intake manifold, at each cylinder . . . . . 7000- 3-1                        |
| Fuel Pump Relay . . . . .            | Front of LH front shock tower, on bracket . . . . . 7000- 0-5                      |
| Fuel Tank Sender . . . . .           | Below RH side of rear seat, top of fuel<br>tank . . . . . 7000- 11-4               |

## 9000-2 COMPONENT LOCATION CHART

---

| COMPONENTS                   | Page-Figure  |
|------------------------------|--|
| Fusible Link A               | RH side of trunk, taped to positive battery cable, near battery . . . . . 7000- 12-1 |
| Gas Filler Lock Motor        | RH side of trunk, behind RH wheel well . . . . . 7000- 12-2                          |
| Glove Box Light Switch       | Behind RH side of dash, above glove box . . . . . 7000- 9-6                          |
| Hazard Switch                | In center of dash, above digital radio . . . . . 7000- 8-6                           |
| Horn Brush/Slip Ring         | In upper part of steering column . . . . . 7000- 7-3                                 |
| Horns                        | Near fog lights, behind splash guard . . . . . 7000- 2-2                             |
| Hot Water Cut-Off Switch     | Behind center of dash, near rotary temperature control . . . . . 7000- 7-6           |
| Idle Speed Actuator          | Top LH side of engine . . . . . 7000- 1-2  |
| Ignition Coil                | On RH front wheel well, forward of shock tower . . . . . 7000- 2-6                   |
| Ignition Key Switch          | Part of ignition switch, in upper part of steering column                            |
| Ignition Switch              | Top RH side of steering column . . . . . 7000- 7-3                                   |
| Interior Light Timer Control | Inside LH kick panel, behind LH front speaker . . . . . 7000- 5-2                    |
| Left Front Crash Sensor      | LH side of engine compartment, behind shock tower . . . . . 7000- 1-1                |
| Left Tank Fuel Sender        | Below LH side of rear seat . . . . . 7000- 11-3                                      |
| Loop Contact Rings           | Inside steering wheel, below air bag gas generator . . . . . 7000- 7-2               |
| Main Fuel Pump               | Below RH side of rear seat, in fuel tank . . . . . 7000- 11-4                        |
| Main Relay                   | Front of LH front shock tower, on bracket . . . . . 7000- 0-5                        |
| Motor Relay                  | Center front of roof, above headliner . . . . . 7000- 8-4                            |
| Motronic Control Unit        | Behind RH side of dash, above glove box . . . . . 7000- 9-6                          |
| Multi-Function Clock         | In center of dash, RH side of digital radio . . . . . 7000- 8-5                      |
| Oil Level Sensor             | Bottom of oil pan . . . . . 7000- 3-3  |
| Oil Pressure Switch          | Lower RH front of engine, below oil filter . . . . . 7000- 3-2                       |
| Outside Temperature Sensor   | Inside air intake, near LH fog light . . . . . 7000- 4-2                             |
| Oxygen Sensor                | Lower RH rear of engine compartment, on exhaust pipe . . . . . 7000- 3-6             |
| Oxygen Sensor Heater Relay   | Front of LH front shock tower, on bracket . . . . . 7000- 0-5                        |
| Park Brake Switch            | Rear of center console, at base of parking brake . . . . . 7000- 9-4                 |
| Power Antenna                | LH side of trunk, behind wheel well . . . . . 7000- 11-6                             |

**COMPONENTS**

Page-Figure

|                            |   |       |      |
|----------------------------|---|-------|------|
| Power Distribution Box     | LH rear corner of engine compartment                              | 7000- | 0-1  |
| Power Window Circuit       |   |       |      |
| Breaker                    | On center console, near gear shift lever                          | 7000- | 9-1  |
| Pulse Wheels               | On respective wheels, in brake housing                            | 7000- | 4-3  |
| Rear Door Lock Motors      | Rear part of respective rear doors                                | 7000- | 10-6 |
| Rear Lights Check Relay    | LH side of trunk, above wheel well                                | 7000- | 11-5 |
| Rear Window Motors         | Forward part of respective front doors                            | 7000- | 10-5 |
| Refrigerant Pressure       |   |       |      |
| Switch                     | On receiver dryer, behind RH headlight                            | 7000- | 2-6  |
| RH Front Door Micro-Switch | In top rear of RH front door                                      | 7000- | 10-3 |
| Right Front Crash Sensor   | RH side of engine compartment, behind shock tower                 | 7000- | 3-4  |
| Safety Switch              | On center console, near gear shift lever                          | 7000- | 9-2  |
| Seatbelt Switch            | In driver's seatbelt buckle assembly                              |       |      |
| Seatbelt Warning Timer     | Behind LH side of dash, on rear of SRS knee pad                   | 7000- | 5-4  |
| Speed Detectors            | On wheels, in brake housing                                       | 7000- | 4-3  |
| Speedometer Sender         | On rear of differential   | 7000- | 12-5 |
| SRS Diagnostic Module      | Behind LH side of dash, above ABS electronic control unit         | 7000- | 5-6  |
| Start Relay                | Behind LH side of dash, on accessory connector bracket            | 7000- | 6-1  |
| Starter                    | Lower LH rear of engine   | 7000- | 1-4  |
| Sunroof Motor              | Center front of roof, above headliner                             | 7000- | 8-4  |
| Throttle Switch            | Below LH side of throttle body                                    | 7000- | 1-6  |
| Trunk Lid Lock Motor       | On trunk lock center support                                      | 7000- | 12-3 |
| Trunk Light Switch         | Top center of trunk lid   | 7000- | 12-4 |
| Unlock Inhibit Switch      | Top rear of LH front door, on door lock cylinder                  | 7000- | 10-3 |
| Washer Fluid Level Switch  | Behind RH front shock tower, in windshield washer fluid reservoir | 7000- | 3-5  |
| Washer Pump                | Behind RH front shock tower, on windshield washer fluid reservoir | 7000- | 3-5  |
| Water Shut-Off Solenoid    | LH side of evaporator housing                                     | 7000- | 8-1  |
| Wiper Motor                | Inside LH side of fresh air intake cowl                           | 7000- | 0-4  |

**CONNECTORS**

|                |  |       |     |
|----------------|--|-------|-----|
| C101 (20 pins) | Next to power distribution box, mounted on engine dash | 7000- | 0-2 |
| C103 (30 pins) | Behind LH side of dash, on body electrical             |       |     |



## 9000-4 COMPONENT LOCATION CHART

### CONNECTORS

Page-Figure

|                |       |  |       |       |      |
|----------------|-------|--|-------|-------|------|
| C104 (2 pins)  | ..... | bracket                                    | ..... | 7000- | 6-2  |
|                |       | Behind LH side of dash, near C302          |       |       |      |
|                |       | accessory connector                        | ..... | 7000- | 6-2  |
| C110 (3 pins)  | ..... | RH front of engine compartment             | ..... | 7000- | 2-6  |
| C113 (3 pins)  | ..... | Behind LH headlight                        | ..... | 7000- | 0-6  |
| C114 (8 pins)  | ..... | LH rear corner of engine compartment, on   |       |       |      |
|                |       | power distribution box                     | ..... | 7000- | 0-3  |
| C115 (2 pins)  | ..... | LH rear corner of engine compartment, on   |       |       |      |
|                |       | power distribution box                     | ..... | 7000- | 0-3  |
| C131 (2 pins)  | ..... | Behind RH side of dash, above glove box    | ..... | 7000- | 9-6  |
| C136 (4 pins)  | ..... | Behind RH side of dash, above glove box    | ..... | 7000- | 9-6  |
| C140 (4 pins)  | ..... | RH rear of engine compartment, under tray  | ..... | 7000- | 3-6  |
| C142 (1 pin)   | ..... | Behind LH side of dash, near steering      |       |       |      |
|                |       | column                                     | ..... | 7000- | 5-5  |
| C143 (1 pin)   | ..... | Behind LH side of dash, near C302          |       |       |      |
|                |       | accessory connector                        | ..... | 7000- | 5-5  |
| C150 (2 pins)  | ..... | Front of LH front shock tower              | ..... | 7000- | 0-5  |
| C151 (2 pins)  | ..... | RH front of engine compartment             | ..... | 7000- | 2-6  |
| C190 (2 pins)  | ..... | Below RH side of rear seat                 | ..... | 7000- | 11-4 |
| C191 (7 pins)  | ..... | Lower LH side of engine                    | ..... | 7000- | 1-4  |
| C200 (10 pins) | ..... | Behind LH side of dash, on steering column | ..... | 7000- | 6-5  |
| C201 (6 pins)  | ..... | Behind LH side of dash, on steering column | ..... | 7000- | 6-5  |
| C202 (13 pins) | ..... | Behind LH side of dash, on steering column | ..... | 7000- | 6-5  |
| C204 (12 pins) | ..... | Behind LH side of dash, RH side of         |       |       |      |
|                |       | steering column                            | ..... | 7000- | 7-5  |
| C208 (2 pins)  | ..... | Behind LH side of dash, base of steering   |       |       |      |
|                |       | column                                     | ..... | 7000- | 5-5  |
| C209 (7 pins)  | ..... | Behind LH side of dash, near brake pedal   |       |       |      |
|                |       | support                                    | ..... | 7000- | 6-1  |
| C210 (7 pins)  | ..... | Behind LH side of dash, on steering column | ..... | 7000- | 6-5  |
| C213 (1 pin)   | ..... | Behind center of dash, on digital radio    | ..... | 7000- | 8-6  |
| C214 (1 pin)   | ..... | Behind center of dash, on digital radio    | ..... | 7000- | 8-6  |
| C215 (2 pins)  | ..... | Behind center of dash, near digital radio  | ..... | 7000- | 8-5  |
| C216 (2 pins)  | ..... | Behind center of dash, on digital radio    | ..... | 7000- | 8-5  |
| C217 (2 pins)  | ..... | Behind center of dash, on digital radio    |       |       |      |
| C218 (2 pins)  | ..... | Behind center of dash, on digital radio    |       |       |      |
| C219 (2 pins)  | ..... | LH side of trunk, above wheel well         | ..... | 7000- | 11-6 |
| C220 (2 pins)  | ..... | Behind LH side of dash                     |       |       |      |
| C221 (2 pins)  | ..... | Behind RH side of dash                     |       |       |      |

**CONNECTORS**

|                                       |       |   |       |       |      |
|---------------------------------------|-------|---|-------|-------|------|
| C222 (1 pin)                          | ..... | Behind LH side of dash, near C302<br>accessory connector    | ..... | 7000- | 6-2  |
| C233 (1 pin)                          | ..... | Behind center of dash, near digital radio                   | ..... | 7000- | 8-5  |
| C240 (6 pins)                         | ..... | Behind LH side of dash, on SRS diagnostic<br>module bracket | ..... | 7000- | 5-6  |
| C241 (1 pin)                          | ..... | Behind LH side of dash, above steering<br>column            | ..... | 7000- | 6-4  |
| C243 (1 pin)                          | ..... | Behind center of dash, near digital radio                   | ..... | 7000- | 8-6  |
| C244 (4 pins)                         | ..... | Behind center of dash, on digital radio                     | ..... | 7000- | 8-5  |
| C245 (2 pins)                         | ..... | Behind center of dash, on digital radio                     |       |       |      |
| C250 (2 pins)                         | ..... | Behind LH side of dash, base of steering<br>column          | ..... | 7000- | 5-5  |
| C260 (2 pins)                         | ..... | Underside of steering column, above access<br>panel         | ..... | 7000- | 7-1  |
| C261                                  | ..... | Under LH side of dash, near C302 accessory<br>connector     |       |       |      |
| C270 (4 pins)                         | ..... | Behind LH side of dash, on SRS diagnostic<br>module bracket | ..... | 7000- | 5-6  |
| C290 (2 pins)                         | ..... | Behind LH side of dash, on SRS diagnostic<br>module bracket | ..... | 7000- | 5-6  |
| C301 (2 pins) (Automatic)             | ..... | Below center console, near gear shift<br>lever              | ..... | 7000- | 9-3  |
| C301 (2 pins) (Manual)                | ..... | Below center console, near gear shift<br>lever              | ..... | 7000- | 9-1  |
| C302 (25 pins) Accessory<br>Connector | ..... | Behind LH side of dash, on body electrical<br>bracket       | ..... | 7000- | 6-2  |
| C303 (3 pins)                         | ..... | At base of RH "B" pillar                                    | ..... | 7000- | 11-1 |
| C304 (3 pins)                         | ..... | At base of LH "B" pillar                                    | ..... | 7000- | 11-1 |
| C305 (1 pin)                          | ..... | Behind LH side of dash, near C302<br>accessory connector    | ..... | 7000- | 6-2  |
| C306 (9 pins)                         | ..... | Below center console, near gear shift<br>lever              | ..... | 7000- | 9-2  |
| C352 (2 pins)                         | ..... | Behind LH side of rear seat                                 | ..... | 7000- | 11-2 |
| C360 (2 pins)                         | ..... | Below RH side of rear seat                                  | ..... | 7000- | 11-4 |
| C401 (7 pins)                         | ..... | In LH "B" pillar  | ..... | 7000- | 10-4 |
| C402 (7 pins)                         | ..... | In RH "B" pillar  | ..... | 7000- | 10-4 |
| C403 (4 pins)                         | ..... | Behind LH side of dash                                      |       |       |      |
| C404 (21 pins)                        | ..... | Above RH front door jamb switch                             | ..... | 7000- | 4-6  |

## 9000-6 COMPONENT LOCATION CHART

---

|                |   |             |      |
|----------------|---|-------------|------|
| C405 (21 pins) | ..... Above LH front door jamb switch                   | ..... 7000- | 4-5  |
| C406 (1 pin)   | ..... Inside RH kick panel, below RH side of<br>speaker | ..... 7000- | 5-1  |
| C407 (1 pin)   | ..... Inside LH kick panel, below RH side of<br>speaker | ..... 7000- | 5-1  |
| C421 (2 pins)  | ..... Underneath LH front seat assembly                 |             |      |
| C422 (2 pins)  | ..... Underneath RH front seat assembly                 |             |      |
| C503 (3 pins)  | ..... In lower rear of LH front door                    | ..... 7000- | 10-3 |
| C510 (1 pin)   | ..... Inside LH kick panel, behind LH front<br>speaker  | ..... 7000- | 5-2  |

### GROUNDS

|      |  |             |      |
|------|--|-------------|------|
| G100 | ..... RH rear corner of trunk, behind battery    | ..... 7000- | 12-2 |
| G103 | ..... Behind RH front shock tower                | ..... 7000- | 3-5  |
| G104 | ..... On inner fender, behind LH headlight       | ..... 7000- | 1-3  |
| G200 | ..... Under LH side of dash, above brake pedal   | ..... 7000- | 6-3  |
| G201 | ..... Upper LH side of steering column           | ..... 7000- | 7-3  |
| G202 | ..... Under LH side of dash, above brake pedal   | ..... 7000- | 6-3  |
| G300 | ..... Behind LH side of rear seat                | ..... 7000- | 11-2 |
| G302 | ..... LH side of trunk, on power antenna bracket | ..... 7000- | 11-6 |
| G600 | ..... Center front of roof, above headliner      | ..... 7000- | 8-4  |